Wireless access point

WEP-550K

User manual

Firmware version 1.4.2

IP address: 192.168.1.10

Username: admin

Password: password

Contents

1 Introduction 5
1.1 Annotation 5
1.2 Symbols 5
2 Device description 6
2.1 Purpose 6
2.2 Device specification 6
2.3 Technical parameters 8
2.4 Radiation patterns 10
2.5 Design 11
2.5.1 Main panel 11
2.5.2 Top panel 12
2.6 Light indication 13
2.7 Restore the default configuration 13
2.8 Supply package 13
3 Rules and recommendations for device installation 14
3.1 Safety rules 14
3.2 Installation recommendations 14
3.3 Calculating the number of required access points 15
3.4 Channel selection for neighboring access points 15
4 Device installation 18
4.1 Device installation on a flat surface 18
4.2 Device installation on Armstrong ceiling 19
4.3 Device installation on a stud 22
4.4 Device installation on VESA100 bracket 24
5 Device management via the web interface 25
5.1 Getting started 25
5.2 Applying configuration and discarding changes 26
5.3 Web interface basic elements 27
5.4 "Monitoring" menu 28
5.4.1 "Wi-Fi Clients" submenu 28
5.4.2 "Traffic Statistics" submenu 29
5.4.3 "Events" submenu 31
5.4.4 "Network Information" submenu 32
5.4.5 "Radio Information" submenu 34
5.4.6 "Device Information" submenu 35
5.5 "Radio" menu 36
5.5.1 "Radio 2.4 GHz" submenu 36
5.5.2 "Radio 5 GHz" submenu 38
5.5.3 "Radio 6 GHz" submenu 40
5.5.4 "Advanced" submenu 42
5.6 "VAP" menu 43

5.6.1 "Summary" submenu 43
5.6.2 "VAP" submenu 44
5.6.3 "MLO" submenu 48
5.7 "Network Settings" menu 50
5.7.1 "System Configuration" submenu 50
5.7.2 "Access" submenu 51
5.8 "External Services" menu 52
5.8.1 "AirTune" submenu 52
5.9 "System" menu 53
5.9.1 "Device Firmware Upgrade" submenu 53
5.9.2 "Configuration" submenu 54
5.9.3 "Reboot" submenu 54
5.9.4 "Password" submenu 55
5.9.5 "Log" submenu 55
5.9.6 "Date and Time" submenu 56
5.9.7 "Troubleshooting" submenu 57
6 Managing the device using the command line 58
6.1 Connection to the device 58
6.2 Configuring network parameters 59
6.2.1 Configuring remote management 60
6.3 Configuring Wi-Fi virtual access points (VAP) 61
6.3.1 Configuring VAP without Encryption 62
6.3.2 Configuring VAP with OWE Encryption 63
6.3.3 Configuring VAP with WPA-Personal security mode 64
6.3.4 Configuring VAP with Enterprise authorization 65
6.3.5 Configuring VAP with external Captive Portal 66
6.3.6 Configuring an additional RADIUS server on VAP 68
6.3.7 Advanced VAP settings 68
6.4 Configuring MLO 76
6.4.1 Configuring MLO Group with OWE 76
6.4.2 Configuring MLO Group with WPA-Personal security mode 77
6.4.3 Configuring MLO Group with Enterprise authorization 77
6.4.4 Advanced MLO settings 77
6.5 Configuring AirTune 78
6.6 Radio settings 79
6.6.1 Advanced Radio settings 80
6.7 Configuring DHCP option 82 81
6.8 System settings 82
6.8.1 Device firmware update 82
6.8.2 Device configuration management 83
6.8.3 Device reboot 83
6.8.4 Configuring the authentication mode 83

6.8.5 Setting the date and time 84
6.8.6 Advanced system settings 84
6.9 Configuring Captive Portal parameters 85
6.10 Configuring DAS server 87
6.11 Configuring multiple controller addresses 87
6.12 Passive radio environment scanning manager configuration 88
6.13 Monitoring 89
6.13.1 Wi-Fi clients 89
6.13.2 Device information 91
6.13.3 Network information 92
6.13.4 Wireless interfaces 94
6.13.5 Event logging 95
6.13.6 Environment scan 95
6.14 Obtaining troubleshooting information 97
7 Auxiliary utilities 98
7.1 traceroute utility 98
7.2 tcpdump utility 98
7.2.1 Capturing traffic from any active interface 98
7.3 iperf utility 98
8 List of changes 99

1 Introduction

1.1 Annotation

Modern tendencies of telecommunication development necessitate operators to search for the most optimal technologies, allowing one to meet rapidly growing needs of subscribers, while maintaining at the same time consistency of business processes, development flexibility and reducing the costs of various services. Wireless technologies are spinning up more and more, and have paced a huge way for short time from unstable low-speed communication networks of low radius to broadband access networks equitable to speed of wired networks with high criteria to the quality of provided services.

The main purpose of WEP-550K is indoor installation as an access point to various resources, creating a seamless wireless network from several identical access points (roaming), if the coverage area is large enough.

This manual specifies intended purpose, main technical parameters, design, safe operation rules, as well as installation and configuration recommendations for WEP-550K.

1.2 Symbols

Notes and warnings

Notes contain important information, tips, or recommendations on device operation and setup.

Warnings are used to inform the user about harmful situations for the device and the user alike, which could cause malfunction or data loss.

2 Device description

2.1 Purpose

The WEP-550K wireless access points are designed to provide the user access to a high-speed and secure network.

The main purpose of the devices is to create a Layer 2 wireless data network at the junction with a wired network. WEP-550K connects to a wired network over the 100M/1G/2.5G/5G/10G Ethernet interface and uses radio interfaces to provide wireless high-speed access for devices that support Wi-Fi technology in the 2.4/5/6 GHz bands.

The devices contain 3 radio interfaces for organizing three physical wireless networks.

WEP-550K supports modern quality of service requirements and allows transmitting the most important traffic in higher priority queues compared to regular traffic. Prioritization is provided by the following QoS technologies: CoS (tags in the VLAN header) and ToS (markings in the IP header).

Support for traffic shaping on each VAP enables full control over service quality and limitations — both for all subscribers collectively and for each subscriber individually.

The device is a flagship solution for building a wireless network with a large number of users and intensive traffic in offices, government institutions, hotels, conference rooms, laboratories, and classrooms. The ability to create virtual access points with different encryption types allows WEP-550K installation in organizations that require access rights separation between regular users and dedicated user groups.

2.2 Device specification

Interfaces:

- 1 port of 100M/1G/2.5G/5G/10G BASE-T (RJ-45) with PoE support;
- 1 port of 100M/1G/2.5G BASE-T (RJ-45) without PoE support;
- Wi-Fi 2.4 GHz IEEE 802.11b/g/n/ax/be;
- Wi-Fi 5 GHz IEEE 802.11a/n/ac/ax/be;
- Wi-Fi 6 GHz IEEE 802.11ax/be.

Functions:

WLAN capabilities:

- support for IEEE 802.11a/b/g/n/ac/ax/be standards;
- support for IEEE 802.11r/k/v user roaming;
- data aggregation, including A-MPDU and A-MSDU;
- WMM-based priorities and packet planning;
- Dynamic Frequency Selection (DFS);
- support for hidden SSID;
- automatic channel selection;
- 48 virtual access points.

Network functions:

- auto-negotiation of speed, duplex mode and switching between MDI and MDI-X modes;
- VLAN;
- C-VLAN;
- DHCP client;
- GRE;
- transmission of subscriber traffic without tunnels;
- NTP;
- Syslog;
- LLDP.

Security:

- centralized authorization via RADIUS server (802.1X WPA/WPA2/WPA3 Enterprise);
- WPA/WPA2/WPA3/OWE encryption;
- support for Captive Portal;
- WIDS support (available under the license).

The WEP-550K equipment use case is shown in Figure 1.




Figure 1 — WEP-550K use case

2.3 Technical parameters

Table 1 — Main specifications

Ethernet interface parameters	
Number of ports	2
Electrical connector	RJ-45
Data rate	100M/1G/2.5G/5G/10G/auto 100M/1G/2.5G/auto
Standards support	BASE-T
Wireless interface parameters	
Standards	802.11a/b/g/n/ac/ax/be
Frequency range	2400–2483.5 MHz; 5150–5350 MHz, 5470–5850 MHz, 5935–7125 MHz
Modulation	BPSK, QPSK, 16QAM, 64QAM, 256QAM, 1024QAM, 4096QAM
Operating channels	802.11b/g/n/ax/be: 1–13 (2401–2483 MHz) 802.11a/n/ac/ax/be: • 36–64 (5170–5330 MHz) • 100–144 (5490–5730 MHz) • 149–165 (5735–5835 MHz) 802.11ax/be: 1–233 (5935–7125 MHz)
Data rate	2.4 GHz, 802.11be: 1376 Mbit/s 5 GHz, 802.11be: 5765 Mbit/s 6 GHz, 802.11be: 11530 Mbit/s
Maximum number of simultaneous connections	1024
Maximum transmitter output power	2.4 GHz: 21 dBm 5 GHz: 21 dBm 6 GHz: 21 dBm
Built-in antenna gain	2.4 GHz: ~4 dBi 5 GHz: ~6 dBi 6 GHz: ~3 dBi
Receiver sensitivity	2.4 GHz: up to -93 dBm 5 GHz: up to -94 dBm 6 GHz: up to -94 dBm
Security	centralized authorization via RADIUS server (802.1X WPA/WPA2/WPA3 Enterprise) WPA/WPA2/WPA3/OWE data encryption support for external authentication portal
Radio interface with OFDMA and MU-MIMO 4×4 support	
Management	
Remote management	web interface, Telnet, SSH, CLI, NETCONF
Access restriction	by password

General parameters	
Flash memory	256 MB SPI-NAND Flash
RAM	1 GB DDR4 RAM
Power supply	PoE++ (IEEE 802.3bt-2018)
Power consumption	no more than 33 W
Operating temperature range	from +5 to +40 °C
Relative humidity at 25 °C	up to 80 %
Dimensions (diameter × height)	280 × 64.5 mm
Weight	1.8 kg
Service life	no less than 15 years

Table 2 — Power supply

Power supply unit	PoE class	Wi-Fi			Ethernet		Maximum power consumption, W
		2.4 GHz	5 GHz	6 GHz	10 GE	2.5 GE	
802.3bt (PoE++)	5	4×4	4×4	4×4	10G	2.5G	33
802.3at (PoE+)	4	2×2	2×2	2×2	2.5G	-	20
Unclassified	-	2×2	2×2	2×2	2.5G	-	20







Some PoE++ injectors may operate incorrectly; the PoE class must be matched with the powered device.
If an incorrect PoE class is supplied to the device, turn the injector off and on, or power the device from another injector/switch.



Table 3 — Compatibility table of network connection speeds and Ethernet cable categories

Speed	Cable category
10G	CAT6a (100 m)
	CAT6 (55 m)
	CAT5e (30 m)
5G	CAT6
	CAT5e (30 m)
2.5G	CAT5e
1G	CAT5e
100M	CAT5

2.4 Radiation patterns

The figures below show the radiation patterns of the device.

Measurement position	
AZIMUTH (XY)	**ELEVATION (XZ)**
	
2.4 GHz band	
	
5 GHz band	
	

6 GHz band	
	

2.5 Design

WEP-550K is enclosed in a plastic case.

2.5.1 Main panel

The main panel layout of the device is shown in Figure 2.




Figure 2 — WEP-550K main panel layout

The following indicator lights, connectors, and controls are placed on the main panel of WEP-550K (see Table 4).

Table 4 — Description of indicators, ports and controls

Element		Description
1	LAN_1	10GE (PoE) port status LED
2	LAN_2	2.5GE port status LED
3	F	Factory reset button
4	10GE (PoE)	10GE port for Ethernet cable connection and PoE++
5	2.5GE	2.5GE port for Ethernet cable connection

2.5.2 Top panel

The top panel layout is shown in Figure 3.




Figure 3 — WEP-550K top panel layout

Table 5 — Description of the top panel indicators

Panel element		Description
1	Power	Device operating status Indicator

2.6 Light indication

The current status of the device is displayed using the **LAN, Power** LEDs. The possible indicator states are described in Table 6.

Table 6 — Light indication of device status

LED	LED status	Description
LAN_1	Solid green (100 Mbps); Solid green, solid orange (1/2.5/5/10 Гбит/с)	The connection with a connected network device is established
	Flashing green	Packet data transmission over LAN interface
LAN_2	Solid green (100 Mbps); Solid green, solid orange (1/2.5/5/10 Gbps)	The connection with a connected network device is established
	Flashing green	Packet data transmission over LAN interface
Power	Solid green	The device power supply is enabled, normal operation
	Solid orange	The device is loaded but IP address is not received via DHCP
	Solid red	The device is loading

2.7 Restore the default configuration

The device can be reset to the factory configuration using the “F” button on the device. When the device is loaded, press and hold the “F“ button (approximately 10–15 seconds) until “Power” indicator is flashing. The device will be rebooted automatically. DHCP client will be launched by default. If the address is not obtained via DHCP, the device will have the factory IP address — *192.168.1.10*, and the following netmask — *255.255.255.0*. Username/password for web interface: admin/password.

2.8 Supply package

The supply package includes:

- WEP-550K radio access equipment;
- mounting kit;
- user manual on a CD (optional);
- technical passport.

3 Rules and recommendations for device installation

This section defines safety rules, installation recommendations, setup procedure and the device starting procedure.

3.1 Safety rules

1. Do not install the device near heat sources or in rooms and at places where temperature may reach values below 5 °C or above 40 °C.
2. Do not use the device in high-humidity areas. Do not expose the device to smoke, dust, water, mechanical vibration, or shock.
3. Do not open the device enclosure. There are no user serviceable parts inside.

To prevent overheating of the device components and malfunction of the device, do not block the ventilation holes with foreign objects and do not place objects on the equipment surface.

3.2 Installation recommendations

1. The recommended installation position: horizontal, on the ceiling.

2. Before installing the device and turning it on, check the device for visible mechanical defects. If defects are observed, stop the device installation, fill in the corresponding act and contact the supplier.

3. If your device has been exposed to the cold for a long period of time, let it warm up at room temperature for two hours before starting work. If your device has been exposed to high humidity for a long period of time, let it stay under normal conditions for at least 12 hours before turning it on.

4. When placing your device, in order to provide the best Wi-Fi coverage consider the following rules:

- Install the device at the center of a wireless network;
- Minimize the number of barriers (walls, ceilings, furniture, and etc.) between the access point and other wireless network devices;
- Do not install the device near electrical and radio devices (about 2 m);
- It is not recommended to use radiophone and other equipment operating at the frequency of 2.4, 5 or 6 GHz , within the range of a Wi-Fi network;
- Obstacles like glass/metal constructions, brick/concrete walls, water cans and mirrors can significantly reduce Wi-Fi action radius. It is not recommended to place the device inside a false ceiling as metal frame causes multipath signal propagation and signal attenuation.

5. When installing several access points, cell action radius must overlap with action radius of a neighboring cell at the level from -65 to -70 dBm. It is allowed to reduce the signal level to -75 dBm at cell boundaries, if it is not intended to use VoIP, video streaming and other sensitive to losses traffic in wireless network.

3.3 Calculating the number of required access points

To calculate the required number of access points, evaluate the required coverage zone. For more accurate assessment, it is necessary to make a radio examination of the room. Approximate radius of WEP-550K coverage area with a good-quality signal in case of mounting on a ceiling in typical office: 2.4 GHz — 40–50 m, 5 GHz/6 GHz — 20–30 m. In the absence of obstacles, the coverage radius: 2.4 GHz — up to 100 m, 5 GHz/6 GHz — up to 60 m.

Table 7 describes approximate attenuation values.

Table 7 — Attenuation values

Material	Change of signal level, dB		
	2.4 GHz	5GHz	6GHz
Drywall	3	3.2	3.5
Brick (9 cm wall)	5	7	8
Concrete (20 cm wall)	12	15	18
Reinforced concrete (30 cm wall)	20	25	30
Standard glass (window)	1	1,5	2
Furniture	1	1,5	2
Wood (hollow/door)	3	4	5
Wood (solid wood/wall)	10	15	20
Metal	25	30	35

3.4 Channel selection for neighboring access points




Figure 4 — Full Wi-Fi frequency spectrum

To avoid inter-channel interference between adjacent access points, it is recommended to set up non-overlapping channels.

When using a 40 MHz channel width in the 2.4 GHz band, there are no non-overlapping channels. In such cases, it is best to choose channels that are as far apart as possible.




Figure 5 — Channels used in the 2.4 GHz band with channel widths of 20 and 40 MHz

Example of channel allocation scheme between adjacent access points in the 2.4 GHz band with channel width of 20 MHz is shown in Figure 6.




Figure 6 — Scheme of channel allocation between adjacent access points in the frequency range of 2.4 GHz when channel width is 20 MHz

Similarly, it is recommended to maintain this channel allocation mechanism when positioning access points between floors (Figure 7).




Figure 7 — Scheme of channel allocation between adjacent access points that are located between floors




Figure 8 — Channels used in the 5 GHz band with channel widths of 20, 40, 80, and 160 MHz




Figure 9 — Channels used in the 6 GHz band with channel widths of 20, 40, 80, 160, and 320 MHz

4 Device installation

The device can be installed on a ceiling profile, stud, flat surface, or VESA100 bracket in compliance with the safety instructions and recommendations listed above.
The device supply package includes required mounting kit to attach the device on a ceiling profile, stud, or flat surface.

4.1 Device installation on a flat surface

The holes for attaching the mounting plate to a flat surface are marked in Figure 10.




Figure 10 — Holes for attaching the mounting plate to a wall/ceiling

1. Secure the mounting plate to the surface using the fasteners from the supply package. The raised edges on the holes should face the mounting surface (Figure 11).




Figure 11 — Mounting plate attachment to surface

2. Connect the cables to the corresponding device connectors. The connector descriptions are provided in Design. Install the device on the mounting plate by aligning the rubber feet with the holes on the plate, Figures 12 (a) and 12 (b).




Figure 12 (a)




Figure 12 (b)

3. Secure the device on the mounting plate by sliding it from position 1 to position 2 (Figure 12 (b)).

4.2 Device installation on Armstrong ceiling

1. To install the device on a ceiling profile, use the ceiling clamp shown in Figure 13.




Figure 13 — Ceiling clamp

2. Spread the clamp to the extreme position and snap it onto the ceiling profile (Figure 14). The provided mounting option is designed for three types of profiles with widths of 15, 24, and 38 mm (see Figure 10).




Figure 14 — Clamp attachment to ceiling profile

3. Secure the mounting plate to the ceiling clamp using M3×5 screws from the supply package, Figure 15.




Figure 15 — Mounting plate attachment to clamp

4. Connect the cables to the corresponding device connectors. The connector descriptions are provided in Design. Install the device on the mounting plate by aligning the rubber feet with the holes on the plate, Figure 16.




Figure 16 — Device installation on the mounting plate

5. Secure the device on the mounting plate by sliding it to the side in the direction of arrow 1, Figure 17 (a). Pay attention to the indicator position (arrow 2 direction) and connectors — they should be located along the profile direction, Figure 17 (b).




Figure 17 (a) — Securing the device on the mounting plate




Figure 17 (b) — Connector arrangement

4.3 Device installation on a stud

1. Install the bracket from the supply package onto the mounting plate using M3×5 screws, Figure 18.




Figure 18 — Bracket installation on mounting plate

2. Screw the mounting plate onto the M10 stud until tight, Figure 19.




Figure 19 — Mounting plate installation on stud

3. Connect the cables to the corresponding device connectors. The connector descriptions are provided in Design. Install the device on the mounting plate by aligning the rubber feet with the holes on the plate, Figure 20.




Figure 20 — Device installation on the mounting plate

4. Secure the device on the plate by sliding it to the side, Figure 21.




Figure 21 — Securing the device on the mounting plate

4.4 Device installation on VESA100 bracket

The design of this device provides for mounting using VESA100 brackets.

1. Unscrew the rubber feet located on the device heatsink (Figure 12 (a)).
2. Attach the bracket to the device.

> Before mounting on a VESA100 bracket, ensure that the mount is capable of supporting the device weight.

5 Device management via the web interface


5.1 Getting started

To get started, connect to the device via the WAN interface using a web browser:

1. Open a web browser, for example Firefox, Opera, Chrome.
2. Enter the device IP address in the browser address bar.

Factory IP address of the device: 192.168.1.10, subnet mask: 255.255.255.0. By default, the device can obtain an address via DHCP.


When the device is successfully detected, a username and password request page will be shown in the browser window.




3. Enter the username in the "Enter login" field and the password in the "Enter password" field.

Factory settings: login — *admin*, password — *password*.

4. Click the "Log In" button. A menu for monitoring the device status will open in the browser window.



5. If necessary, you can switch the information display language.



5.2 Applying configuration and discarding changes

1. Applying configuration

Clicking the Apply button starts the process of saving the configuration to the device flash memory and applying the new settings. All the settings come into operation without device rebooting.

The WEP-550K web interface provides visual indication of the current status of the settings application process (Table 8).

Table 8 — Visual indication of the current status of the settings application process

Image	State description
Apply	After clicking the "Apply" button, the process of applying the settings and writing them to the device memory starts. This is indicated by the icon in the tab name and on the "Apply" button.
Apply	The icon in the tab name indicates successful saving and application of the settings.


2. Discarding changes

The changes can be discarded only before clicking the "Apply" button. If you click the "Apply" button, the parameters changed on the page will be updated to the current values stored in the device memory. After clicking the "Apply" button, return to the previous settings will not be possible.

The button for discarding changes appears as follows: Cancel .

5.3 Web interface basic elements

Navigation elements of the web interface are shown in the figure below.



User interface window is divided into five areas:

1. Menu tabs to group submenus by categories: **Monitoring, Radio, VAP, Network Settings, External Services, System**.
2. Interface language selection and the "Logout" button, designed to end a session in the web interface under a given user.
3. Submenu tabs to control the settings field.
4. Device configuration field for viewing data and configuration.
5. Information field displaying the firmware version installed on the device.


5.4 "Monitoring" menu

In the **"Monitoring"** menu, the current system state can be viewed.

5.4.1 "Wi-Fi Clients" submenu

The **"Wi-Fi Clients"** submenu displays information about the status of connected Wi-Fi clients.

Information on connected clients is not displayed in real time. In order to update the information on the page, click the "Refresh" button.



- *#* — number of the connected device in the list;
- *Hostname* — network name of the device;
- *IP address* — IP address of the connected device;
- *MAC* — MAC address of the connected device;
- *Interface* — WEP-550K interaction interface with the connected device;
- *Link Capacity* — parameter that displays the efficiency of modulation on the transmission used by an access point. It is calculated based on the number of packets transmitted to the client on each modulation, and the reduction factors. The maximum value is 100% (means that all packets are transmitted to the client at maximum modulation for the maximum nss type supported by the client). The minimum value is 2% (in the case when the packets are transmitted on the modulation nss1mcs0 for a client with MIMO 3×3 support). The parameter value is calculated for the last 10 seconds;
- *Link Quality* — parameter that displays the status of the link to the client, calculated based on the number of retransmit packets sent to the client. The maximum value is 100% (all transmitted packets were sent on the first attempt), the minimum value is 0% (no packets were successfully sent to the client). The parameter value is calculated for the last 10 s;
- *RSSI, dBm* — received signal level, dBm;
- *SNR, dB*— signal/noise ratio, dB;
- *TxRate* — channel data rate of transmission, Mbps;
- *RxRate* — channel data rate of receiving, Mbps;
- *Tx BW, MHz* — transmission bandwidth, MHz;
- *Rx BW, MHz* — reception bandwidth, MHz;
- *Uptime* — Wi-Fi client connection time.

To display more detailed information on a particular client, select it from the list.

A detailed description includes the following parameters:


- *Total TX/RX, bytes* — number of bytes sent/received on the connected device;
- *Total TX/RX, packets* — number of packets sent/received on the connected device;
- *Fails, packets* — number of packets sent with errors on the connected device.

5.4.2 "Traffic Statistics" submenu

The "**Traffic Statistics**" submenu displays the graphs of the speed of transmitted/received traffic for the last 2 minutes, as well as statistics on the amount of transmitted/received traffic since the access point was turned on.

The LAN Tx/Rx diagram shows the speed of the transmitted/received traffic via Ethernet interface (ETH0) of the access point for the last 2 minutes. The graph is automatically updated every 6 seconds.

The WLAN0, WLAN1 and WLAN2 Tx/Rx graphs show the speed of the transmitted/received traffic via Radio 2.4 GHz, Radio 5 GHz and Radio 6 GHz interfaces for the last 2 minutes. The graph is automatically updated every 6 seconds.



"*Transmit*" table description:

- *Interface* — name of the interface;
- *Total Packets* — number of successfully sent packets;
- *Total Bytes* — number of successfully sent bytes;
- *Total Drop* — number of packets dropped when sending;
- *Errors* — number of errors.

Transmit

Interface	Total Packets	Total Bytes	Total Drop	Errors
LAN	13656	6744400	0	0
WLAN0	0	0	0	0
WLAN1	7791	6841216	156	156
erspan0	0	0	0	0
eth1	0	0	0	0
ip6gre0	0	0	0	0
ip6tnl0	0	0	0	0
wlan1-apcli0	0	0	0	0
wlan2	0	0	0	0
wlan2-apcli0	0	0	0	0

"*Receive*" table description:


- *Interface* — name of the interface;
- *Total Packets* — number of successfully received packets;
- *Total Bytes* — number of successfully received bytes;
- *Total Drop* — number of packets dropped when receiving;
- *Errors* — number of errors.

Receive

Interface	Total Packets	Total Bytes	Total Drop	Errors
LAN	31894	12668940	78	0
WLAN0	0	0	0	0
WLAN1	7228	1578656	1448	1448
erspan0	0	0	0	0
eth1	0	0	0	0
ip6gre0	0	0	0	0
ip6tnl0	0	0	0	0
wlan1-apcli0	0	0	0	0
wlan2	0	0	0	0
wlan2-apcli0	0	0	0	0

5.4.3 "Events" submenu

In the "**Events**" submenu, it is possible to view a list of real-time informational messages which contains the following information:



- *Date and Time* — date and time when the event was generated;
- *Type* — category and severity level of the event;
- *Service* — name of the process that generated the message;
- *Message* — event description.

Table 9 — Event importance category descriptions


Level	Message severity level	Description
0	Emergency	A critical error has occurred in the system; the system may not work properly
1	Alert	Immediate intervention is required
2	Critical	A critical error has occurred in the system
3	Error	An error has occurred in the system
4	Warning	Warning, non-emergency message
5	Notice	System notice, non-emergency message
6	Informational	Informational system messages
7	Debug	Debugging messages provide the user with information to correctly configure the system

To receive new messages in the event log, click "Refresh".

If necessary, all old messages can be deleted from the log by clicking on the "Clear" button.

5.4.4 "Network Information" submenu

In the "**Network Information**" submenu, general network settings of the device can be viewed.



WAN Status:

- *Interface* — name of the bridge interface;
- *Protocol* — protocol used for access to WAN;
- *IP Address* — device IP address in external network;

Ethernet:

- *Link Status* — Ethernet port status;
- *Speed* — Ethernet port connection speed;
- *Duplex* — data transfer mode:
  - *Full* — full duplex;
  - *Half* — half-duplex.
- *RX Bytes* — number of bytes received on ETH;
- *TX Bytes* — number of bytes sent from ETH.

ARP:
The ARP table contains mapping information between the IP and MAC addresses of neighboring network devices:

- *IP address* — device IP address;
- *MAC* — device MAC address.

Routes:


- *Interface* — name of the bridge interface;
- *Destination* — IP address of destination host or subnet that the route is established to;
- *Gateway* — IP address of the gateway through which access to the destination is carried out;
- *Netmask* — subnet mask;
- *Flags* — certain route characteristics.

The following flag values exist:

- **U** — means that the route is created and passable.
- **H** — indicates the route to the specific host.
- **G** — means that the route lies through external gateway. System network interface provides routes in the network with direct connection. All other routes lie through the external gateways. G flag is used for all routes except for the routes in the direct connection networks.
- **R** — indicates that the route was most likely created by a dynamic routing protocol running on the local system using the reinstate parameter.
- **D** — indicates that the route was added as a result of receiving an ICMP Redirect Message. When the system learns the route from the ICMP Redirect message, the route will be added into the routing table in order to exclude redirection for the following packets intended for the same destination.
- **M** — means that the route was modified — likely by a dynamic routing protocol running on a local system with the "mod" parameter applied.
- **A** — points to a buffered route to which an entry in the ARP table corresponds.
- **C** — means that the route source is the core routing buffer.
- **L** — indicates that the destination of the route is one of the addresses of this computer. Such "local routes" exist in the routing buffer only.
- **B** — means that the route destination is a broadcasting address. Such "broadcast routes" exist in the routing buffer only.
- **I** — indicates that the route is connected to a ring (loopback) interface for a purpose other than to access the ring network. Such "internal routes" exist in the routing buffer only.
- **!** — means that datagrams sent to this address will be rejected by the system.

5.4.5 "Radio Information" submenu

In the "**Radio Information**" submenu, the current status of the WEP-550K radio interfaces is displayed.



The access point radio interfaces can be in two states: "On" and "Off". The status of each radio interface is shown in the identically named "Status" parameter.
The Radio status depends on whether the radio interface has any enabled virtual access points (VAPs). In case there is at least one active VAP on the radio interface, Radio will be in "On" status, otherwise — "Off".

Depending on the Radio status, the following information is available for monitoring:

"Off":


- *Status* — radio interface state;
- *MAC* — radio interface MAC address;
- *Mode* — radio interface operation mode according to IEEE 802.11 standards.

"On":

- *Status* — radio interface state;
- *MAC* — radio interface MAC address;
- *Mode* — radio interface operation mode according to IEEE 802.11 standards;
- *Channel* — number of the wireless channel on which the radio interface is running;
- *Channel Bandwidth, MHz* — bandwidth of the channel on which the radio interface is running.

5.4.6 "Device Information" submenu

In the "**Device Information**" submenu, the main WEP-550K specifications are displayed.




- *Product* — device model name;
- *Hardware Version* — device hardware version;
- *Factory MAC address* — device WAN interface MAC address, factory set;
- *Serial Number* — device serial number, factory set;
- *Software Version* — device software version;
- *Backup Version* — previously installed firmware version;
- *Boot Version* — device firmware boot version;
- *System Time* — current time and date, set in the system;
- *Power Type* — standard of the power supply currently in use:
  - *PoE++;*
  - *PoE+;*
  - *PoE/Unclassified.*
- *Uptime* — operating time since the last time the device was turned on or rebooted;
- *CPU Usage* — average percentage of CPU load over the last 5 seconds;
- *Memory Usage* — percentage of device RAM usage.

5.5 "Radio" menu

In the "**Radio**" menu, the radio interfaces of the device can be configured.

5.5.1 "Radio 2.4 GHz" submenu

In the "**Radio 2.4 GHz**" submenu, the main parameters of the radio interface of the device operating in the 2.4 GHz band can be configured.



To connect devices in the IEEE 802.11be (Wi-Fi 7) standard, it is recommended to configure WPA2/WPA3, WPA3, or OWE security mode.


- *Mode* — interface operation mode according to the following standards:
  - *IEEE 802.11b/g/n;*
  - *IEEE 802.11b/g/n/ax;*
  - *IEEE 802.11b/g/n/ax/be.*
- *Auto Channel* — when checked, the device will automatically select the least congested radio channel for the Wi-Fi interface. Unchecking the flag opens the access to install the static operation channel;
- *Channel* — select channel for data transmission;
- *Use Limit Channels* — when checked, the access point will use a user-defined list of channels to work in automatic channel selection mode. If the "Use Limit Channels" flag is not checked or there are no channels in the list, the access point will select the operation channel from all available channels in the given band. 2.4 GHz band channels: 1–13;
- *Channel Bandwidth, MHz* — the bandwidth of the channel on which the access point operates, accepts values 20 and 40 MHz;
- *Primary Channel* — the parameter can only be changed if the bandwidth of a statically specified channel is equal to 40 MHz. The 40 MHz channel can be considered as consisting of two 20 MHz channels, which border in the frequency domain. These two
  20 MHz channels are called primary and secondary channels. The primary channel is used by clients who only support of 20 MHz channel bandwidth:
  - *Upper* — the primary channel will be the upper 20 MHz channel in the 40 MHz band;
  - *Lower* — the primary channel will be the lower 20 MHz channel in the 40 MHz band.
- *Transmit Power Limit, dBm* — adjustment of the signal strength of the Wi-Fi transmitter in dBm. Accepts values from 0 to 16 dBm.

If the "Use Limit Channels" list contains a channel that is not available for selection, it will be marked in grey. For the new configuration to be applied to the access point, only available (highlighted in blue) channels must be specified in the "Use Limit Channels" list.
Example. No settings have been made on the access point yet, "Channel Bandwidth" is set to 20 MHz by default on Radio 2.4 GHz, and the channels specified in the "Use Limit Channels" list are: 1, 6, 11. Suppose the "Channel Bandwidth" parameter needs to be set to 40 MHz. When this parameter is changed from 20 MHz to 40 MHz, the following happens:

- The "Primary Channel" parameter becomes available for editing and takes the default value "Lower",
- The channel 11 in the "Use Limit Channels" list changes its color from blue to grey.

If you change the "Channel Bandwidth" parameter to 40 MHz and do not remove the grey channels from the list, then when you click the "Apply" button an error "There are errors in data. Changes were not applied" will appear in the browser. Accordingly, the access point configuration will not be changed. This happens because the channels highlighted in grey in the "Use Limit Channels" list do not fit the definition "Primary Channel" = Lower.

In the "Advanced" section, advanced parameters of the device radio interface are configured.




- *OBSS Coexistence* — automatic channel bandwidth reduction when the radio environment is congested. When the flag is set, the mode is enabled;
- *Short Guard Interval* — support for Short Guard Interval. The access point transmits data using a 400 ns guard interval (instead of 800 ns) when communicating with clients that also support Short Guard Interval;
- *STBC* — Space-Time Block Coding method aimed at improving data transmission reliability. When the flag is set, the device transmits one data stream through several antennas. If the flag is not set, the device does not transmit the same data stream through several antennas;
- *Beacon Interval, ms* — the period of Beacon frame transmission. The frames are transmitted so that the access point can be detected in the radio environment. The parameter accepts values 20–2000 ms, default — 100 ms;
- *Fragmentation Threshold* — frame fragmentation threshold in bytes. Accepts values 256–2346, default — 2346;
- *RTS Threshold* — specifies the number of bytes after which a Request to Send is sent. Decreasing this value may improve the access point performance when there are many connected clients, however it reduces the overall throughput of the wireless network. Accepts values 0–2347, default — 2347;
- *Short Preamble* — use of the short packet preamble.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.5.2 "Radio 5 GHz" submenu

In the "**Radio 5 GHz**" submenu, the main parameters of the radio interface of the device operating in the 5 GHz band can be configured.



To connect devices in the IEEE 802.11be (Wi-Fi 7) standard, it is recommended to configure WPA2/WPA3, WPA3 or OWE security mode.


- *Mode* — interface operation mode according to the following standards:
  - *IEEE 802.11 a/n/ac;*
  - *IEEE 802.11a/n/ac/ax;*
  - *IEEE 802.11a/n/ac/ax/be.*
- *Auto Channel* — when checked, the access point will automatically select the least congested radio channel for the Wi-Fi interface. When unchecked, access to set the static operating channel becomes available;
- *Channel* — select channel for data transmission;
- *Use Limit Channels* — when checked, the access point will use a user-defined list of channels to work in automatic channel selection mode. If the "Use Limit channels" flag is not checked or there are no channels in the list, the access point will select the operation channel from all available channels in the given band. 5 GHz band channels: 36–64, 132–144, 149–165;
- *Channel Bandwidth, MHz* — channel bandwidth on which the access point operates; takes values 20, 40, 80 and 160 MHz;
- *Primary Channel* — parameter can only be changed if the bandwidth of a statically specified channel is equal to 40 MHz. The 40 MHz channel can be considered as consisting of two 20 MHz channels, which border in the frequency range. These two 20 MHz channels are called primary and secondary channels. The primary channel is used by clients who only support 20 MHz channel bandwidth:
  - *Upper* — primary channel will be the upper 20 MHz channel in the 40 MHz band;
  - *Lower* — primary channel will be the lower 20 MHz channel in the 40 MHz band.
- *Transmission Power Limit, dBm* — adjustment of the Wi-Fi transmitter signal power in dBm. Takes values from 0 to 19 dBm.

If the "Use Limit channels" list contains a channel that is not available for selection, it will be marked in grey. In order for the new configuration to be applied to the access point, only available (highlighted in blue) channels must be specified in the "Use Limit channels" list.
Example. No settings have been made on the access point yet; by default, Radio 5 GHz has "Channel Bandwidth" set to 20 MHz, and the "Use Limit channels" list specifies the channels: 36, 40, 44, 48. Suppose it is required to set "Channel Bandwidth" to 40 MHz. When this parameter is changed from 20 MHz to 40 MHz, the following happens:

- The "Primary Channel" becomes available for editing and takes the default value "Upper",
- The 36 and 44 channels in the "Use Limit Channels" list changes its color from blue to grey.

If you change the "Channel Bandwidth" parameter to 40 MHz and do not remove the grey channels from the list, then when you click the "Apply" button an error "There are errors in data. Changes were not applied" will appear in the browser. Accordingly, the access point configuration will not be changed. This happens because the channels highlighted in grey in the "Use Limit Channels" list do not fit the definition "Primary Channel" = Lower.

In the "Advanced" section, advanced parameters of the device radio interface are configured.




- *OBSS Coexistence* — automatic channel bandwidth reduction when the radio environment is congested. When the flag is set, the mode is enabled;
- *DFS Support* — mechanism that requires wireless devices to scan the radio spectrum and avoid using channels that overlap with those used by radar systems in the 5 GHz band:
  - *Disabled* — mechanism is disabled. DFS channels are not available for selection;
  - *Enabled* — mechanism is enabled;
  - *Forced* — mechanism is disabled. DFS channels are available for selection.
- *Short Guard Interval* — support for Short Guard Interval. The access point transmits data using a 400 ns guard interval (instead of 800 ns) when communicating with clients that also support Short Guard Interval;
- *STBC* — Space-Time Block Coding method aimed at improving data transmission reliability. When the flag is set, the device transmits one data stream through several antennas. If the flag is not set, the device does not transmit the same data stream through several antennas;
- *Beacon Interval, ms* — the period of Beacon frame transmission. The frames are transmitted so that the access point can be detected in the radio environment. The parameter accepts values 20–2000 ms, default — 100 ms;
- *Fragmentation Threshold* — frame fragmentation threshold in bytes. Accepts values 256–2346, default — 2346;
- *RTS Threshold* — specifies the number of bytes after which a Request to Send is sent. Decreasing this value may improve the access point performance when there are many connected clients, however it reduces the overall throughput of the wireless network. Accepts values 0–2347, default — 2347;
- *Short Preamble* — use of the short packet preamble.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.5.3 "Radio 6 GHz" submenu

In the "**Radio 6 GHz**" submenu, the main parameters of the radio interface of the device operating in the 6 GHz band can be configured.



To connect devices in the IEEE 802.11be (Wi-Fi 7) standard, it is recommended to configure the security mode WPA2/WPA3, WPA3 or OWE.

For 6 GHz, only the OWE, WPA3, WPA3-Enterprise security modes are available.

- *Mode* — interface operation mode according to the following standards:
  - *IEEE 802.11ax;*
  - *IEEE 802.11ax/be.*
- *Auto Channel* — when checked, the device will automatically select the least congested radio channel for the Wi-Fi interface. Unchecking the flag opens the access to install the static operation channel;
- *Channel* — select channel for data transmission;
- *Use Limit Channels* — when checked, the access point will use a user-defined list of channels to work in automatic channel selection mode. If the "Use Limit Channels" flag is not checked or there are no channels in the list, the access point will select the operation channel from all available channels of the given frequency band. 6 GHz band channels: 1–93;
- *Channel Bandwidth, MHz* — channel bandwidth, on which the access point operates. The parameter may take values 20, 40, 80, 160, and 320 MHz;
- *Primary Channel* — parameter can only be changed if the bandwidth of a statically specified channel is equal to 40 MHz or 320 MHz.
  - The 40 MHz channel can be considered as consisting of two 20 MHz channels, which border in the frequency range. These two 20 MHz channels are called primary and secondary channels. The primary channel is used by clients who only support 20 MHz channel bandwidth:
    - *Upper* — primary channel will be the upper 20 MHz channel in the 40 MHz band;
    - *Lower* — primary channel will be the lower 20 MHz channel in the 40 MHz band.
  - The 320 MHz channel can be considered as consisting of two 160 MHz bands, which border in the frequency range. The channel used by clients who only support 20 MHz bandwidth may be located in one of these bands:
    - *Upper* — the 20 MHz data transmission channel will be located in the upper 160 MHz band;
    - *Lower* — the 20 MHz data transmission channel will be located in the lower 160 MHz band.


- *Transmission Power Limit, dBm* — adjustment of the signal strength of the Wi-Fi transmitter in dBm. Accepts values from 0 to 19 dBm.

If a channel unavailable for selection is specified in the "Use Limit Channels" list, it will be marked in grey. For the new configuration to be applied on the access point, only available (highlighted in blue) channels must be specified in the "Use Limit Channels" list.
Example. No settings have been made on the access point yet, Radio 5 GHz is set to 20 MHz "Channel Bandwidth" by default, and channels are specified in the "Use Limit Channels" list: 1, 5, 9, 13.
Suppose it is required to set the "Channel Bandwidth" parameter to 40 MHz. When you change this parameter from 20 MHz to 40 MHz, the following happens:

- The "Primary Channel" parameter becomes available for editing and the default value is "Upper",
- The 1 and 9 channels in the "Use Limit Channels" list change their color from blue to grey.

If you change the "Channel Bandwidth" parameter to 40 MHz and do not remove the grey channels from the list, then when you click the "Apply" button in the browser an error will appear — "There are errors in data. Changes were not applied". Accordingly, the access point configuration will not be changed. This is due to the fact that channels highlighted in grey in the "Use Limit Channels" list do not fit the definition "Primary Channel" = Upper.

In the "Advanced" section, advanced radio interface parameters of the device are configured.




- *OBSS Coexistence* — automatic channel bandwidth reduction when the radio environment is loaded. When the flag is set, the mode is enabled;
- *Short Guard Interval* — support for Short Guard Interval. The access point transmits data using a 400 ns guard interval (instead of 800 ns) when communicating with clients which also support Short Guard Interval;
- *STBC* — Space-Time Block Coding method aimed at improving data transmission reliability. When checked, the device transmits one data flow through several antennas. When unchecked, the device does not transmit the same data flow through several antennas;
- *Beacon Interval, ms* — beacon frames transmission period. The frames are transmitted for the access point to be detected in the radio environment; takes values 20–2000 ms, default: 100 ms;
- *Fragmentation Threshold* — frame fragmentation threshold in bytes. Takes values 256–2346, default: 2346;
- *RTS Threshold* — specifies the number of bytes over which the Request to Send will be sent. Decreasing this value may improve the performance of the access point when there are a lot of connected clients. However, this reduces general throughput of wireless network. The parameter takes values 0–2347, by default: 2347;
- *Short Preamble* — use of the packet short preamble.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.5.4 "Advanced" submenu

In the "**Advanced**" submenu, it is possible to configure advanced radio interface parameters of the device.



- *Country* — the name of the country in which the access point operates. Select the "Unlock" checkbox to change a country. Depending on the selected value, the channel bandwidth and transmit power limit restrictions in effect in the selected country will be applied. The list of available frequency channels depends on the selected country, which affects the automatic channel selection in the Channel = Auto mode. If the client device is licensed for use in a different region, probably, a connection with the access point will not be established.

  Configuring local (regional) restrictions, including operation within legal frequency channels and output power, is the installer's responsibility.

  Selecting the wrong region may result in compatibility issues with different client devices.


To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.6 "VAP" menu

The **"VAP"** menu is used to configure Wi-Fi virtual access points (VAP) and Multi-link Operation (MLO) groups.

5.6.1 "Summary" submenu


The "**Summary**" submenu displays the settings of all VAPs on the Radio 2.4 GHz, Radio 5 GHz, and Radio 6 GHz radio interfaces, as well as the MLO group settings. You can view the settings of each virtual access point in the VAP0–VAP15 sections and of MLO groups in the 0–15 sections.



- *VAP0–VAP15* — ordinal number of the virtual access point;
- *1-15* — ordinal number of the MLO group;
- *Enabled* — when this check box is selected, the virtual access point is enabled; otherwise, it is disabled;
- *Security mode* — type of data encryption used on the virtual access point;
- *VLAN ID* — VLAN number from which the tag is removed when transmitting traffic to Wi-Fi clients connected to this VAP. When traffic passes in the reverse direction, the VLAN ID tag will be added to untagged traffic from clients;
- *SSID* — virtual wireless network name;
- *Broadcast SSID* — when this check box is selected, SSID broadcasting is enabled; otherwise, it is disabled;
- *Band Steer mode* — when this check box is selected, client connections to the 5 GHz network are actively prioritized. To use this function, you need to create a VAP with an identical SSID on at least two radio interfaces and enable the "Band Steer mode" parameter on them;
- *Station Isolation* — when this check box is selected, traffic isolation between clients within a single VAP is enabled.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.6.2 "VAP" submenu




General settings:

- *Enabled* — when this check box is selected, the virtual access point is enabled; otherwise, it is disabled;
- *VLAN ID* — VLAN number from which the tag is removed when transmitting traffic to Wi-Fi clients connected to this VAP. When traffic passes in the reverse direction, the VLAN ID tag will be added to untagged traffic from clients;
- *SSID* — virtual wireless network name;
- *Broadcast SSID* — when this check box is selected, SSID broadcasting is enabled; otherwise, it is disabled;
- *Band Steer* — when this check box is selected, client connections to the 5 GHz network are actively prioritized. To use this function, you need to create a VAP with an identical SSID on at least two radio interfaces and enable the "Band Steer mode" parameter on them;
- *Station Isolation* — when this check box is selected, traffic isolation between clients within a single VAP is enabled;
- *802.11k/v* — enable support for the 802.11k/v standards on the virtual access point;
- *Minimal Signal* — when this check box is selected, the function of disconnecting client devices at a low signal level (Minimal Signal) is enabled. For the functionality to work, the following parameters need to be configured:
  - *Minimum Signal Level, dBm* — signal strength (in dBm) below which a client device is disconnected from the virtual network;
  - *Minimal Signal Timeout, s* — time period after which a decision is made to disconnect a client device from the virtual network.
- *Maximum Stations* — maximum number of clients that can connect to the virtual network;
- *Security mode* — wireless network access security mode:

To connect devices in the IEEE 802.11be (Wi-Fi 7) standard, it is recommended to configure the WPA2/WPA3, WPA3 or OWE security mode.

For 6 GHz, only the OWE, WPA3, WPA3-Enterprise security modes are available.


- *Off* — do not use encryption for data transmission. The access point is available for any client to connect;
- *OWE (Opportunistic Wireless Encryption)* — encryption method that ensures the security of data transmitted over an unsecured network.
  No additional actions or password entry are required from users to connect to the network.
  WPA, WPA2, WPA/WPA2, WPA2/WPA3, WPA3 — encryption methods; when one of them is selected, the following setting becomes available:
  - *WPA Key* — key/password required to connect to the virtual access point. The key length is from 8 to 63 characters.
- *WPA-Enterprise, WPA2-Enterprise, WPA/WPA2-Enterprise, WPA2/WPA3-Enterprise, WPA3-Enterprise* — wireless channel encryption mode in which the client is authorized on a centralized RADIUS server. To configure this security mode, the RADIUS server parameters must be specified. A key for the RADIUS server must also be specified. When a specific security mode is selected, the following settings become available.



- *MFP* — management frame protection (available in security modes WPA2, WPA3, WPA2/WPA3, WPA2-Enterprise, WPA2/WPA3-Enterprise and WPA3-Enterprise; when other security modes are selected, MFP is set to *Not Required*; when security mode WPA3, WPA3-Enterprise is selected, MFP is set to *Required*):
  - *Not Required* — management frame protection is disabled;
  - *Capable* — protection works if the client supports MFP. Clients without MFP support can connect to this VAP;
  - *Required*— protection is enabled, clients that do not support MFP cannot connect.
- *PMKSA Caching* — a flag that controls enabling caching of Enterprise client connection information. When this function is enabled, the access point remembers the client device for 12 hours after authorization and does not require re-authentication on the RADIUS server when connecting within this time. Enabling this function reduces roaming time when the client returns to the access point in WPA Enterprise mode. The setting is available only in Enterprise security modes;
- *802.11r Support* — fast roaming function, works only with clients that support the IEEE 802.11r standard. 802.11r roaming is possible only between VAPs with security modes WPA2, WPA3, WPA2/WPA3, WPA2-Enterprise, WPA3-erprise, WPA2/WPA3-Enterprise.
  - *802.11r Support* — enable support for the 802.11r standard on a virtual access point;
  - *Manual* — when the check box is selected, you can manually configure roaming parameters;
  - *FT-over-DS* — enabling the "Over the DS" mode;
  - *R0-key-holder-id* — unique key for this VAP, for example, a serial number;


- *R1-key-holder-id* — MAC address of the VAP (can be viewed in the output of the ifconfig command);
- *Mobility Domain* — group number within which roaming can be performed. Accepts values from 0 to 65535;
- *Remote MAC:*
  - *MAC* — MAC address of the VAP interface of the remote access point. Maximum number — 256;
  - *Remote-R0-key-holder-id* — unique key, must match "R0-key-holder-id" on the VAP of the remote access point;
  - *Remote-R1-key-holder-id* — MAC address of the VAP on the remote access point;
  - *RRB-key-R0* — random key. Must not match "RRB-key-R1", but must match the "RRB-key-R1" of the remote access point. Key length — 16 characters;
  - *RRB-key-R1* — random key. Must not match "RRB-key-R0", but must match the "RRB-key-R0" of the remote access point. Key length — 16 characters.

RADIUS:



- *Domain* — user domain;
- *IP Address of RADIUS server* — RADIUS server address;
- *Port of RADIUS server* — RADIUS server port used for authentication and authorization;
- *Password of RADIUS server* — password for the RADIUS server used for authentication and authorization;
- *Use Accounting through RADIUS* — when the check box is selected, "Accounting" messages will be sent to the RADIUS server;
- *Use Other Settings For Accounting:*
  - *IP Address of RADIUS Server for Accounting* — address of the RADIUS server used for accounting;
  - *Password of RADIUS Server for Accounting* — password for the RADIUS server used for accounting;
- *Port of RADIUS Server for Accounting* — port that will be used for collecting accounting on the RADIUS server;
- *Password of RADIUS Server* — password for the RADIUS server used for authentication and authorization;
- *Use Periodic Accounting* — enable periodic sending of "Accounting" messages to the RADIUS server. The message sending interval can be set in the "Accounting Interval" field.

Shapers:



Enable — activate the setting field:

- *VAP Limit Down* — limiting the bandwidth in the direction from the access point to the clients (in total) connected to this VAP;
- *VAP Limit Up* — limiting the bandwidth in the direction from the clients (in total) connected to this VAP, to the access point;
- *STA Limit Down* — limiting the bandwidth in the direction from the access point to the clients (each separately) connected to this VAP;
- *STA Limit Up* — limiting the bandwidth in the direction from the clients (each separately) connected to this VAP, to the access point.

Advanced — activate the advanced setting field:


- *Broadcast Limit Down* — limiting the bandwidth of broadcast traffic in the direction from the access point to clients;
- *Broadcast Limit Up* — limiting the bandwidth of broadcast traffic from clients toward the access point;
- *Multicast Limit Down* — limiting the bandwidth of multicast traffic in the direction from the access point to clients;
- *Multicast Limit Up* — limiting the bandwidth of multicast traffic from clients toward the access point.

The following parameters are available for configuring restrictions:

- *Off*— bandwidth limitation does not apply;
- *kbps* — bandwidth limitation is applied in kbps;
- *pps* — bandwidth limitation is applied in pps.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.6.3 "MLO" submenu




MLO (Multi-Link Operation) is a key feature of the Wi-Fi 7 standard that allows a device (for example, a smartphone) to connect to an access point over multiple bands (2.4 GHz, 5 GHz, and 6 GHz) simultaneously.

MLO group with index N uses VAPs with index N across all radio bands; consequently, the settings for the corresponding VAPs become inaccessible when the MLO group is enabled.

Common Settings:

- *Enabled* — when the check box is selected, the virtual access point is enabled; otherwise, it is disabled;
- *SSID* — name of the virtual wireless network name;
- *VLAN ID* — VLAN number from which the tag will be removed when transmitting Wi-Fi traffic to clients connected to this MLO group. When traffic flows in the opposite direction, untagged traffic from clients will be tagged with VLAN ID;
- *Security Mode* — security mode of wireless network access:
  - *OWE (Opportunistic Wireless Encryption)* — encryption method that ensures the security of data transmitted over an insecure network.
    Moreover, users are not required to take any additional steps or enter a password to connect to the network.
  - *WPA3* — encryption methods; selecting one of these methods will make the following setting available:
    - *WPA Key* — key/password required to connect to the virtual access point. The key must be between 8 and 63 characters long.
  - *WPA3-Enterprise* — wireless channel encryption mode in which the client is authorized on a centralized RADIUS server. To configure this security mode, the RADIUS server parameters must be specified (see below).
- *MFP* — management frame protection (available when using WPA2, WPA3, WPA2/WPA3, WPA2-Enterprise, WPA2/WPA3-Enterprise, or WPA3-Enterprise security modes; if other security modes are selected, MFP is set to *Not Required*, while for WPA3 or WPA3-Enterprise security modes, MFP is set to *Required*):
  - *Required* — protection is enabled, clients that do not support MFP cannot connect (the option value is set by default, and no other options are provided in this mode).

RADIUS:




- *Domain* — user domain;
- *IP Address of RADIUS Server* — RADIUS server address;
- *Port of RADIUS Server* — port for the RADIUS server used for authentication and authorization;
- *Password of RADIUS Server* — password for the RADIUS server used for authentication and authorization.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.7 "Network Settings" menu

5.7.1 "System Configuration" submenu



- *Hostname* — network name of the device, specified as a string of 1–63 characters: Latin uppercase and lowercase letters, digits, hyphen "-" (the hyphen cannot be the last character in the name);
- *AP Location* — domain of the device tree node of the EMS management system in which the access point is located;
- *Protocol* — select protocol for connection of the device via Ethernet interface to service provider network:
  - *DHCP* — operation mode, when IP address, subnet mask, DNS server address, default gateway and other parameters required for operation are obtained from DHCP server automatically;
  - *Static* — operation mode, when IP address and all the necessary parameters for WAN interface are assigned statically. If "Static" is selected, the following parameters will be available to set:
    - *Static IP* — IP address of the device WAN interface in the provider network;
    - *Netmask* — external subnet mask;
    - *Gateway* — address, to which the packet is sent, if the route in routing table is not found for it.
- *Primary DNS server, Secondary DNS server* — IP addresses of DNS servers. If addresses of DNS servers are not automatically assigned via DHCP, set them manually.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.


5.7.2 "Access" submenu

In the "**Access**" submenu, access to the device via the web interface, Telnet, SSH, NETCONF can be configured.

- To enable access to the device via the web interface via HTTP protocol, set the flag next to "WEB". In the window that appears, it is possible to change the HTTP port (by default: 80). The range of acceptable values of ports, in addition to the default, from 1025 to 65535 inclusive;
- To enable access to the device via the web interface via HTTPS protocol, set the flag next to "WEB-HTTPS". In the window that appears, it is possible to change the HTTPS port (by default: 443). The range of acceptable values of ports, in addition to the default, from 1025 to 65535 inclusive;

> The ports for the HTTP and HTTPS protocols should not have the same value.

- To enable access to the device via Telnet, check the box next to "Telnet";
- To enable access to the device via SSH, check the box next to "SSH";
- To enable access to the device via NETCONF, check the box next to "NETCONF".




To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.8 "External Services" menu

5.8.1 "AirTune" submenu

The "**AirTune**" submenu is intended to enable and configure the AirTune service on the access point.

The AirTune service is used to optimize radio resources (Radio Resource Management) and to automatically configure seamless 802.11 k/r roaming.



- *Enable* — when checked, the access point will connect to the AirTune service, the address of which is specified in the "AirTune Service Address" field, to provide Radio Resource Management functions and/or 802.11 k/r roaming;
- *AirTune URL* — AirTune service address. It is specified in the format: "ws://<host>:<port>/apb/rrm".


To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.9 "System" menu

In the "**System**" menu, you can configure the system, time, and access to the device over various protocols, change the password, and update the device firmware.

5.9.1 "Device Firmware Upgrade" submenu

The "**Device Firmware Upgrade**" submenu is intended for upgrading the device firmware.



- *Active Version* — installed firmware version, which is operating at the moment;
- *Backup version* — firmware version installed on the device that you can switch to without uploading a firmware file.
  - *Set active* — button that makes the backup firmware version active; a device reboot is required. The active firmware version then becomes the backup one.


Firmware upgrade

Download the firmware file from the https://eltex-co.com/download website, selecting WEP-550K in the list of devices, and save it on your computer. After that, click "Choose File" in the *Firmware Image* field and specify the path to the firmware file in .tar.gz format.
To start the update process, click the "Start Upgrading" button. The update process will take several minutes (its current status will be shown on the page), after which the device will automatically reboot.

Do not disconnect the device from the power supply and do not reboot it during the firmware update process.

5.9.2 "Configuration" submenu

The "**Configuration**" submenu is used to save and restore the current configuration.



Download configuration

To save the current device configuration to a local computer, click the "Download" button.

Restore Configuration


To load a configuration file saved on a local computer, the "*Restore Configuration*" item is used. To update the device configuration, click the "Choose file" button, specify the file (in .tar.gz format), and click the "Upload File" button. The uploaded configuration is applied automatically without rebooting the device.

Reset to Default Configuration

To reset all device settings to the standard factory defaults, click the "Reset" button. If the "Save access setting" check box is enabled, those configuration parameters that control access to the device (IP address configuration, Telnet/SSH/NETCONF/Web access settings) will be retained.


5.9.3 "Reboot" submenu

To reboot the device, click the "Reboot" button. The device restart process takes approximately 1.5 minutes.




5.9.4 "Password" submenu

When logging in via the web interface, the administrator (default password: **password**) has full access to the device: reading and writing of any settings, full monitoring of the device status.
To change the password, first enter the new password in the "Password" field, then in the "Confirm Password" field, and click the "Apply" button to save the new password.



5.9.5 "Log" submenu

The "**Log**" submenu is intended for configuring the output of various system debug messages to identify the causes of device operation problems.




- *Mode* — Syslog agent operating mode:
  - *Local File* — log information is saved to a local file and is available in the device web interface on the "Monitoring/Events";
  - *Server and File* — log information is sent to a remote Syslog server and saved to a local file.
- *Syslog Server Address* — IP address or domain name of the Syslog server;
- *Syslog Server Port* — port for incoming messages of the Syslog server (default — 514, acceptable values 1–65535);
- *File Size, KB* — maximum log file size (acceptable values 1–1000 KB).

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.9.6 "Date and Time" submenu

In the "**Date and Time**" submenu, the time can be configured manually or using the time synchronization protocol (NTP).


5.9.6.1 Manual



- *Date and Time device* — date and time on the device at the moment. If correction is required, click the "Edit" button.
  - *Date, Time* — set the current date and time or click the "Set current date and time" button to set the device time from your PC.
- *Time Zone* — allows you to set the time zone according to the nearest city in your region from the given list;
- *Enable daylight saving time* — when the check box is selected, the transition between summer/winter time will be performed automatically in the specified time period:
  - *DST Start* — day and time when the transition to daylight saving time will be performed;
  - *DST End* — day and time when the transition to standard time will be performed;
  - *DST Offset (minutes)* — time period in minutes by which the time is shifted. Can take a value from 0 to 720 minutes.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.


5.9.6.2 NTP server



- *Date and Time device* — date and time on the device at the moment;
- *NTP Server* — IP address/domain name of the time synchronization server. You can set the address or select it from the existing list;
- *Time Zone* — allows you to set the time zone according to the nearest city in your region from the given list;
- *Enable daylight saving time* — when the check box is selected, the transition between summer/winter time will be performed automatically in the specified time period:
  - *DST Start* — day and time when the transition to daylight saving time will be performed;
  - *DST End* — day and time when the transition to standard time will be performed;
  - *DST Offset (minutes)* — the time period in minutes by which the time is shifted. Can take a value from 0 to 720 minutes.

To apply a new configuration and save settings to non-volatile memory, click "Apply". Click "Cancel" to discard the changes.

5.9.7 "Troubleshooting" submenu



Troubleshooting File

To download the archive *troubleshooting.tar.gz* from the device to a local computer, click the "Download" button.

6 Managing the device using the command line

To display the available settings of a specific configuration section, enter the **show-config** command.
To view hints about what values a device configuration parameter can take, press the key combination (in English layout) **[Shift + ?]**.
To obtain a list of parameters available for editing in this configuration section, press the **Tab** key.
To save settings, enter the **save** command.
To go to the previous configuration section, enter the **exit** command.
To go to the root section, enter the **end** command.

6.1 Connection to the device

By default, the WEP-550K device is configured to obtain an IP address via DHCP. If this does not occur, you can connect to the device via the factory IP address.

Factory IP address of the WEP-550K device: **192.168.1.10**, subnet mask: **255.255.255.0**.

Connection to the device is performed via SSH/Telnet:

ssh admin@<device IP address>, then enter the password

telnet <device IP address>, enter login and password

6.2 Configuring network parameters

Configuring static network parameters of the access point

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **br0**
WEP-550K(config):/interface/br0# **common**
WEP-550K(config):/interface/br0/common# **static-ip X.X.X.X** (where X.X.X.X is the IP address of WEP-550K)
WEP-550K(config):/interface/br0/common# **netmask X.X.X.X** (where X.X.X.X is the subnet mask)
WEP-550K(config):/interface/br0/common# **dns-server-1 X.X.X.X** (where X.X.X.X is the IP address of DNS server No. 1)
WEP-550K(config):/interface/br0/common# **dns-server-2 X.X.X.X** (where X.X.X.X is the IP address of DNS server No. 2)
WEP-550K(config):/interface/br0/common# **protocol static-ip** (change operation mode from DHCP to Static-IP)
WEP-550K(config):/interface/br0/common# **save** (save settings)

Adding a static route:

WEP-550K(config):/interface/br0/common# **exit**
WEP-550K(config):/interface/br0# **exit**
WEP-550K(config):/interface# **exit**
WEP-550K(config):/# **route**
WEP-550K(config):/route# **add default** (where default is the route name)
WEP-550K(config):/route# **default**
WEP-550K(config):/route/default# **destination X.X.X.X** (where X.X.X.X is IP address of the destination network or node, for default route — 0.0.0.0)
WEP-550K(config):/route/default# **netmask X.X.X.X** (where X.X.X.X is destination network mask, for the default route — 0.0.0.0)
WEP-550K(config):/route/default# **gateway X.X.X.X** (where X.X.X.X is gateway IP address)
WEP-550K(config):/route/default# **save** (save settings)

Configuring network parameter reception via DHCP

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **br0**
WEP-550K(config):/interface/br0# **common**
WEP-550K(config):/interface/br0/common# **protocol dhcp**
WEP-550K(config):/interface/br0/common# **save** (save settings)

6.2.1 Configuring remote management

Configuring SSH

WEP-550K(root):/# **configure**
WEP-550K(config):/# **ssh**
WEP-550K(config):/ssh# **enable true** (remote access management via SSH. To disable, enter **false**. By default: true)
WEP-550K(config):/ssh# **port X** (where X is the SSH server port. By default: 22)
WEP-550K(config):/ssh# **session-limit X** (where X is the maximum number of SSH sessions. By default: 7)
WEP-550K(config):/ssh# **save** (save settings)

Configuring Telnet

WEP-550K(root):/# **configure**
WEP-550K(config):/# **telnet**
WEP-550K(config):/telnet# **enable true** (remote access management via Telnet. To disable, enter **false**. By default: false)
WEP-550K(config):/telnet# **port X** (where X is the port. By default: 23)
WEP-550K(config):/telnet# **session-limit X** (where X is the maximum number of Telnet sessions. By default: 7)
WEP-550K(config):/telnet# **save** (save settings)

6.3 Configuring Wi-Fi virtual access points (VAP)

When configuring a VAP, keep in mind that interface names in the 2.4 GHz band start with wlan0, in the 5 GHz band — wlan1, and in the 6 GHz band — wlan2.

To connect devices supporting the IEEE 802.11be (Wi-Fi 7) standard, it is recommended to configure WPA2/WPA3, WPA3 or OWE security mode.

For 6 GHz, only OWE, WPA3, WPA3-Enterprise security modes are available.

Table 10 — Commands for configuring security mode on VAP

Security mode	Command to set the security mode
Without password	mode off
WPA	mode WPA
WPA2	mode WPA2
WPA/WPA2	mode WPA_WPA2
WPA3	mode WPA3
WPA2/WPA3	mode WPA2_WPA3
OWE	mode OWE
WPA-Enterprise	mode WPA_1X
WPA2-Enterprise	mode WPA2_1X
WPA/WPA2-Enterprise	mode WPA_WPA2_1X
WPA2/WPA3-Enterprise	mode WPA2_WPA3_1X
WPA3-Enterprise	mode WPA3_1X

Below are examples of VAP configuration with different security modes for Radio 5 GHz (wlan1).

6.3.1 Configuring VAP without Encryption

Creating a VAP without encryption with periodic sending of accounting to the RADIUS server

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan1-vap0**
WEP-550K(config):/interface/wlan1-vap0# **vap**
WEP-550K(config):/interface/wlan1-vap0/vap# **ssid 'SSID_WEP-550K_open'** (change SSID name)
WEP-550K(config):/interface/wlan1-vap0/vap# **ap-security**
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **mode off** (encryption mode off — without password)
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius**
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-enable true** (enable sending of "Accounting" messages to the RADIUS server. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-password secret** (where secret is the password for the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-periodic true** (enable periodic sending of "Accounting" messages to the RADIUS server.By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-interval 600** (interval of sending "Accounting" messages to the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **exit**
WEP-550K(config):/interface/wlan1-vap0# **common**
WEP-550K(config):/interface/wlan1-vap0/common# **enabled true** (enable the virtual access point)
WEP-550K(config):/interface/wlan1-vap0/common# **save** (save settings)

6.3.2 Configuring VAP with OWE Encryption

Only Wi-Fi 6 and higher clients will be able to connect to a VAP with OWE security mode.

Creating a VAP with OWE Encryption

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan1-vap0**
WEP-550K(config):/interface/wlan1-vap0# **vap**
WEP-550K(config):/interface/wlan1-vap0/vap# **ssid 'SSID_WEP-550K_owe'** (change SSID name)
WEP-550K(config):/interface/wlan1-vap0/vap# **ap-security**
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **mode OWE** (encryption mode OWE — encrypted connection without entering a password. In this mode, Wi-Fi 6 and higher clients will be able to connect)
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius**
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-enable true** (enable sending of "Accounting" messages to the RADIUS server. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-password secret** (where secret is the password for the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-periodic true** (enable periodic sending of "Accounting" messages to the RADIUS server. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-interval 600** (interval of sending "Accounting" messages to the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **exit**
WEP-550K(config):/interface/wlan1-vap0# **common**
WEP-550K(config):/interface/wlan1-vap0/common# **enabled true** (enable the virtual access point)
WEP-550K(config):/interface/wlan1-vap0/common# **save** (save settings)

6.3.3 Configuring VAP with WPA-Personal security mode

Creating a VAP with WPA-Personal security mode with periodic sending of accounting to the RADIUS server

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan1-vap0**
WEP-550K(config):/interface/wlan1-vap0# **vap**
WEP-550K(config):/interface/wlan1-vap0/vap# **ssid 'SSID_WEP-550K_Wpa2'** (change SSID name)
WEP-550K(config):/interface/wlan1-vap0/vap# **ap-security**
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **mode WPA_WPA2** (encryption mode — WPA/WPA2)
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **key-wpa password123** (key/password required to connect to the virtual access point. The key length must be from 8 to 63 characters)
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius**
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-enable true** (enable sending of "Accounting" messages to the RADIUS server. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-password secret** (where secret is the password for the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-periodic true** (enable periodic sending of "Accounting" messages to the RADIUS server. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-interval 600** (interval of sending "Accounting" messages to the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **exit**
WEP-550K(config):/interface/wlan1-vap0# **common**
WEP-550K(config):/interface/wlan1-vap0/common# **enabled true** (enable the virtual access point)
WEP-550K(config):/interface/wlan1-vap0/common# **save** (save settings)

6.3.4 Configuring VAP with Enterprise authorization

Creating a VAP with WPA2-Enterprise security mode with periodic sending of accounting to the RADIUS server

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan1-vap0**
WEP-550K(config):/interface/wlan1-vap0# **vap**
WEP-550K(config):/interface/wlan1-vap0/vap# **ssid 'SSID_WEP-550K_enterprise'** (change SSID name)
WEP-550K(config):/interface/wlan1-vap0/vap# **ap-security**
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **mode WPA_WPA2_1X** (encryption mode — WPA/WPA2-Enterprise)
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius**
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **domain root** (where root is the user domain)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-port X** (where X is the RADIUS server port used for authentication and authorization. By default: 1812)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-password secret** (where secret is the password for the RADIUS server used for authentication and authorization)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-enable true** (enable sending of "Accounting" messages to the RADIUS server. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-password secret** (where secret is the password for the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-periodic true** (enable periodic sending of "Accounting" messages to the RADIUS server. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-interval 600** (interval of sending "Accounting" messages to the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **exit**
WEP-550K(config):/interface/wlan1-vap0# **common**
WEP-550K(config):/interface/wlan1-vap0/common# **enabled true** (enable the virtual access point)
WEP-550K(config):/interface/wlan1-vap0/common# **save** (save settings)

When Enterprise authorization is used, the C-VLAN assigned on the RADIUS server takes priority for servicing the client. The VLAN value is transmitted in the Tunnel-Private-Group-Id RADIUS attribute.

6.3.5 Configuring VAP with external Captive Portal

Commands to configure the external Captive Portal

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan1-vap0**
WEP-550K(config):/interface/wlan1-vap0# **vap**
WEP-550K(config):/interface/wlan1-vap0/vap# **vlan-id X** (where X is the VLAN-ID on the VAP)
WEP-550K(config):/interface/wlan1-vap0/vap# **ap-security**
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **mode off** (encryption mode off — without password)
WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **ssid 'Portal_WEP-550K'** (change SSID name)
WEP-550K(config):/interface/wlan1-vap0/vap# **captive-portal**
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **verification-mode external-portal** (enable external Captive Portal support. By default: portal)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **scenarios**
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal/scenarios# **scenario-redirect**
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal/scenarios/scenario-redirect# **redirect-url "https://X.X.X.X/<NAS_ID>/?switch_url=<SWITCH_URL>&ap_mac=<AP_MAC>&client_mac=<CLIENT_MAC>&wlan=<SSID>&original-url=<ORIGINAL_URL>&nas-ip=<NAS_IP>&ap_location=<AP_LOCATION>&nas_id=<NAS_ID>"** (specify the URL of the external virtual portal according to the table 11)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal/scenarios/scenario-redirect# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal/scenarios# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **enabled true** (enable the captive portal functionality)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius**
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server used for authorization)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-password secret** (where secret is the password for the RADIUS server used for authorization)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Additional commands to configure the external Captive Portal

WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **preauth-filter-mode acl**
(parameter that determines how traffic from unauthorized clients will be filtered. Possible values: **acl**, **white-list**. By default: white-list)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **http-auth false** (disable authorization via http. By default: true)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **ipv4-acl ipv4_list** (where ipv4_list — name list rules ipv4-acl)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **url-acl url_list** (where url_list — name list rules url-acl)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **filter-dns-by-acl true** (enable DNS request filtering by preauth-acl rules. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **client-mac-format XX-XX-XX-XX-XX-XX** (where XX-XX-XX-XX-XX-XX is the client MAC address format that will be substituted instead of **<AP_MAC>** in requests to the external portal. Possible values: **XX-XX-XX-XX-XX-XX**, **XX:XX:XX:XX:XX:XX**, **XXXXXXXXXXXX**, **xx-xx-xx-xx-xx-xx**, **xx:xx:xx:xx:xx:xx**, **xxxxxxxxxxxx**. By default: xxxxxxxxxxxx)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **nas-id-format XX-XX-XX-XX-XX-XX** (where XX-XX-XX-XX-XX-XX is the access point MAC address format that will be substituted instead of **<NAS_ID>** in requests to the external portal. Possible values: **XX-XX-XX-XX-XX-XX**, **XX:XX:XX:XX:XX:XX**, **XXXXXXXXXXXX**, **xx-xx-xx-xx-xx-xx**, **xx:xx:xx:xx:xx:xx**, **xxxxxxxxxxxx**. By default: xxxxxxxxxxxx)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **disconnect-on-reject true** (parameter responsible for disconnecting the client after receiving Access-Reject. To disable, enter **false**)
WEP-550K(config):/interface/wlan1-vap0/vap/captive-portal# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius**
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **use-macaddr-as-password true** (transmit the client MAC address as the password in RADIUS requests. By default: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **macaddr-format XX-XX-XX-XX-XX-XX** (where XX-XX-XX-XX-XX-XX is the client MAC address format to be used in RADIUS requests. This feature works only when use-macaddr-as-password = true. Possible values: **XX-XX-XX-XX-XX-XX**, **XX:XX:XX:XX:XX:XX**, **XXXXXXXXXXXX**, **xx-xx-xx-xx-xx-xx**, **xx:xx:xx:xx:xx:xx**, **xxxxxxxxxxxx**. By default: xxxxxxxxxxxx)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

To get information about the interaction algorithm with the external portal, see the scheme.

Table 11 — Configuring the URL template for external captive portal authorization

Parameter	Description
<NAS_ID>	NAS ID set on VAP or in system. If neither of these parameters is set, then the MAC address of the access point in the "nas-id-format" format will be used as the NAS ID in RADIUS and HTTP(S) packets
<NAS_IP>	IP address of the access point
<SWITCH_URL>	Domain name displayed to the client upon redirection
<AP_MAC>	MAC address of the access point
<CLIENT_MAC>	MAC address of the client
<SSID>	SSID
<ORIGINAL_URL>	URL initially requested by the client
<AP_LOCATION>	AP location of the access point

6.3.6 Configuring an additional RADIUS server on VAP

This function is available only for captive portal and Enterprise authorization modes.

Commands for configuring an additional RADIUS server on a VAP

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan1-vap0**
WEP-550K(config):/interface/wlan1-vap0# **vap**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius** (configure the main RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **backup** (configure an additional RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup# **add <IP address of the additional RADIUS server in the configuration>** (create an additional RADIUS server configuration section. Maximum number: 4)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup# **X.X.X.X** (where X.X.X.X is the IP address of the additional RADIUS server in the configuration)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **auth-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **auth-port X** (where X is the RADIUS server port used for authentication and authorization. Default: 1812)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **auth-password secret** (where secret is the password for the RADIUS server used for authentication and authorization)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **acct-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **acct-port X** (where X is the RADIUS server port used for accounting. Default: 1813)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **acct-password secret** (where secret is the password for the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **order 1** (where order is the RADIUS server priority. If the priority was not explicitly specified, it is considered to be 0. In this case, the server selection order will correspond to the order in which the RADIUS server was added to the configuration)
WEP-550K(config):/interface/wlan1-vap0/vap/radius/backup/X.X.X.X# **save** (save settings)

6.3.7 Advanced VAP settings

Assigning a VLAN ID on a VAP

WEP-550K(config):/interface/wlan1-vap0/vap# **vlan-id X** (where X is the VLAN ID number on the VAP)

Choosing a prioritization method

WEP-550K(config):/interface/wlan1-vap0/vap# **priority-by-dscp false** (analysis of the priority from the CoS (Class of Service) field of tagged packets. Default: true. In this case, the priority from the DSCP field in the IP packet header is analyzed)

Enabling Band Steer mode

WEP-550K(config):/interface/wlan1-vap0/vap# **band-steer-mode true** (enable the Band Steer mode. To disable, enter **false**)

Enabling MFP mode (802.11W)

WEP-550K(config):/interface/wlan1-vap0/vap/ap-security# **mfp required** (enable protection of management frames. **required** — MFP support is required from the client, clients without MFP will not be able to connect. **capable** — compatible with MFP, clients without MFP support can connect. To disable, enter **off**)

Enabling TLS during authorization

WEP-550K(config):/interface/wlan1-vap0/vap/radius# **tls-enable true** (use TLS during authorization. To disable, enter **false**)

Enabling hidden SSID

WEP-550K(config):/interface/wlan1-vap0/vap# **hidden true** (enable hidden SSID. To disable, enter **false**)

Enabling client isolation on a VAP

WEP-550K(config):/interface/wlan1-vap0/vap# **station-isolation true** (enable traffic isolation between clients within a single VAP. To disable, enter **false**)

Limiting the number of clients on a VAP

WEP-550K(config):/interface/wlan1-vap0/vap# **sta-limit X** (where X is the maximum allowed number of clients that can connect to the virtual network)

Enabling Minimal Signal

WEP-550K(config):/interface/wlan1-vap0/vap# **check-signal-enable true** (enable the use of the Minimal Signal feature. To disable, enter **false**)
WEP-550K(config):/interface/wlan1-vap0/vap# **min-signal X** (where X is the RSSI threshold value at which the access point will start disconnecting clients from the VAP. The parameter can take values from -100 to -1)
WEP-550K(config):/interface/wlan1-vap0/vap# **check-signal-timeout X** (where X is the time period in seconds after which a decision is made to disconnect the client device from the virtual network)
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Enabling subscriber traffic transmission outside a GRE tunnel

WEP-550K(config):/interface/wlan1-vap0/vap# **local-switching true** (enable subscriber traffic transmission outside a GRE tunnel. To disable, enter **false**. Disabled by default)

Configuring data rate limit

Configuring the shaper in the direction from the clients (each individually) connected to a given VAP towards the access point:

WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-per-sta-rx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-sta-rx# **value X** (where X — maximum data rate in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-sta-rx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** — pps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-sta-rx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring the shaper in the direction from the access point to the clients (each individually) connected to a given VAP:

WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-per-sta-tx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-sta-tx# **value X** (where X — maximum data rate in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-sta-tx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** —kbps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-sta-tx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring the shaper from the clients connected to a given VAP (in total) towards the access point:

WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-per-vap-rx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-vap-rx# **value X** (where X — maximum data rate in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-vap-rx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** — kbps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-vap-rx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring the shaper from the access point to the clients (in total) connected to a given VAP:

WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-per-vap-tx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-vap-tx# **value X** (where X — maximum data rate in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-vap-tx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** — kbps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-per-vap-tx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring the broadcast traffic limit

Configuring the shaper in the direction from the client to the access point:
WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-bcast-rx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-bcast-rx# **value X** (where X — maximum data rate in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-bcast-rx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** — kbps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-bcast-rx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring the shaper in the direction from the access point to the client:
WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-bcast-tx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-bcast-tx# **value X** (where X — maximum data rate in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-bcast-tx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** — kbps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-bcast-tx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring the multicast traffic limit

Configuring the shaper in the direction from the client to the access point:
WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-mcast-rx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-mcast-rx# **value X** (where X — maximum data rate in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-mcast-rx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** — kbps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-mcast-rx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring the shaper in the direction from the access point to the client:
WEP-550K(config):/interface/wlan1-vap0/vap# **shaper-mcast-tx**
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-mcast-tx# **value X** (where X — maximum speed in kbps or pps)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-mcast-tx# **mode kbps** (enable the shaper. Possible values: **kbps** — kbps, **pps** — kbps, **off** — disabled)
WEP-550K(config):/interface/wlan1-vap0/vap/shaper-mcast-tx# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring MAC-based access control via a RADIUS server

WEP-550K(config):/interface/wlan1-vap0/vap# **acl**
WEP-550K(config):/interface/wlan1-vap0/vap/acl# **mode radius** (select the radius mode — checking MAC addresses via the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/acl# **policy allow** (select the policy. Possible values: **allow** — allow connection only for those clients that were approved by the RADIUS server; **deny** — deny connection for clients that were approved by the RADIUS server. Default value: deny)
WEP-550K(config):/interface/wlan1-vap0/vap/acl# **enable true** (enable MAC-based access control via the RADIUS server. To disable, enter **false**)
WEP-550K(config):/interface/wlan1-vap0/vap/acl# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **radius**
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **domain root** (where root is the user domain)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-port X** (where X is the RADIUS server port used for authentication and authorization. Default value: 1812)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **auth-password secret** (where secret is the password for the RADIUS server used for authentication and authorization)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-enable true** (enable sending of "Accounting" messages to the RADIUS server. Default value: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-password secret** (where secret is the password for the RADIUS server used for accounting)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-periodic true** (enable periodic sending of "Accounting" messages to the RADIUS server. Default value: false)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **acct-interval 600** (interval of sending "Accounting" messages to the RADIUS server)
WEP-550K(config):/interface/wlan1-vap0/vap/radius# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap# **save** (save settings)

Configuring 802.11r

This type of roaming is available only for client devices that support 802.11r.

802.11r roaming is possible only between VAPs with WPA2/WPA3-Personal and WPA2/WPA3-Enterprise security modes.
For instructions on configuring a VAP with WPA2-Personal security mode and others, see the section Configuring VAP with WPA-Personal security mode.

Each VAP on the access points must be configured individually, for example, AP1(wlan1) ↔ AP2(wlan1), AP1(wlan0) ↔ AP2(wlan0), AP1(wlan1) ↔ AP3(wlan1), etc.

Below is an example of configuring 802.11r on two access points: AP1 and AP2.

Configuring 802.11r on AP1

WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **enabled false**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **r1-key-holder-id E8:28:C1:FC:D6:80** (VAP MAC address. Can be viewed in the output of the **ifconfig** command)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **r0-key-holder-id 12345** (unique key for this VAP)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **mobility-domain 100** (domain must match on remote VAPs)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **mac**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac# **add E4:5A:D4:E2:C4:B0** (MAC address of the VAP interface of the remote access point — AP2)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac# **E4:5A:D4:E2:C4:B0**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E4:5A:D4:E2:C4:B0# **r0-kh-id 23456** (unique key of the remote VAP of access point AP2 — r0-key-holder-id)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E4:5A:D4:E2:C4:B0# **r1-kh-id E4:5A:D4:E2:C4:B0** (MAC address of the remote VAP on AP2)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E4:5A:D4:E2:C4:B0# **r0-kh-key 0102030405060708** (random key. Must not match the r1-kh-key of AP1, but must match the r1-kh-key of the remote AP2)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E4:5A:D4:E2:C4:B0# **r1-kh-key 0001020304050607** (random key. Must not match the r0-kh-key of AP1, but must match the r0-kh-key of the remote AP2)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E4:5A:D4:E2:C4:B0# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **enabled true** (enable access point operation over the 802.11r protocol)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **save** (save settings)

Configuring 802.11r on AP2

WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **enabled false**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **r1-key-holder-id E4:5A:D4:E2:C4:B0** (VAP MAC address. Can be viewed in the output of the **ifconfig** command)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **r0-key-holder-id 23456** (unique key for this VAP)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **mobility-domain 100** (domain must match on remote VAPs)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **mac**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac# **add E8:28:C1:FC:D6:80** (MAC address of the VAP interface of the remote access point — AP1)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac# **E8:28:C1:FC:D6:80**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E8:28:C1:FC:D6:80# **r0-kh-id 12345** (unique key of the remote VAP of access point AP1 — r0-key-hold er-id)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E8:28:C1:FC:D6:80# **r1-kh-id E8:28:C1:FC:D6:80** (MAC address of remote VAP on AP1)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E8:28:C1:FC:D6:80# **r0-kh-key 0001020304050607** (random key. Must not match the r1-kh-key of AP2, but must match the r1-kh-key of the remote AP1)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E8:28:C1:FC:D6:80# **r1-kh-key 0102030405060708** (random key. Must not match the r0-kh-key of AP2, but must match the r0-kh-key of the remote AP1)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac/E8:28:C1:FC:D6:80# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config/mac# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **enabled true** (enable access point operation over the 802.11r protocol)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **save** (save settings)

Configuring 802.11k

Roaming over the 802.11k protocol can be organized between any networks (open/encrypted). If the access point is configured for 802.11k operation, then when a client connects, the access point sends it a list of "friendly" access points to which the client can switch during roaming. The list contains information about the MAC addresses of the access points and the channels on which they operate.

Using 802.11k reduces the time spent searching for another network while roaming, since the client does not need to scan the channels on which there are no target access points available for switching.

This type of roaming is available only for client devices that support 802.11k.

Below is an example of configuring 802.11k on an access point — compiling a list of "friendly" access points.

Configuring 802.11k

WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **enabled false**
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **mac**
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac# **add E8:28:C1:FC:D6:90** (where E8:28:C1:FC:D6:90 is the MAC address of the "friendly" access point)
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac# **E8:28:C1:FC:D6:90**
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac/E8:28:C1:FC:D6:90# **channel 132** (where 132 is the channel on which the access point with MAC address E8:28:C1:FC:D6:90 operates)
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac/E8:28:C1:FC:D6:90# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac# **add E8:28:C1:FC:D6:70** (where E8:28:C1:FC:D6:70 is the MAC address of the "friendly" access point)
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac# **E8:28:C1:FC:D6:70**
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac/E8:28:C1:FC:D6:70# **channel 36** (where 36 is the channel on which the access point with MAC address E8:28:C1:FC:D6:70 operates)
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac/E8:28:C1:FC:D6:70# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config/mac# **exit**
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **enabled true** (enable access point operation over the 802.11k protocol)
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **save** (save settings)

Configuring 802.11v

Roaming over the 802.11v protocol can be organized between any networks (open/encrypted). If the access point is configured for 802.11v operation, then during its operation the device sends a special packet (BSS Transition) toward the client upon command from the administrator/controller (AirTune) with a recommendation for the client to roam. Whether the client device follows the access point's advice or not cannot be guaranteed, since ultimately the decision to switch to another access point is made by the client side. In combination with the 802.11k standard, the handover recommendation message also conveys to the client a list of access points recommended for roaming, indicating the channel on which each access point operates and the standard it uses (IEEE 802.11n/ac/ax). After that, the client analyzes the radio environment and makes a decision depending on the signal level, channel loading, and configuration of the remote access point.

This type of roaming is available only for client devices that support 802.11v.

Configuring 802.11v

WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **enabled true** (enable access point operation over the 802.11k/v protocol)

WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **save** (save settings)

6.4 Configuring MLO

MLO group uses one VAP from each band (2.4, 5 and 6 GHz), the number of the used VAP being N, where N is the group number. For example MLO group 4 uses the following VAPs: wlan0-vap4, wlan1-vap4 and wlan2-vap4.
When an MLO group is enabled, settings of the corresponding VAP will be ignored.

6.4.1 Configuring MLO Group with OWE

Creating an MLO group with OWE encryption mode

WEP-550K(root):/# **configure**
WEP-550K(config):/# **mlo**
WEP-550K(config):/mlo# **mlo-group**
WEP-550K(config):/mlo/mlo-group# **1**
WEP-550K(config):/mlo/mlo-group/1# **ssid SSID_WEP-550K_MLO_owe** (change SSID name)
WEP-550K(config):/mlo/mlo-group/1# **ap-security**
WEP-550K(config):/mlo/mlo-group/1/ap-security# **mode OWE** (encryption mode — OWE)
WEP-550K(config):/mlo/mlo-group/1/ap-security# **exit**
WEP-550K(config):/mlo/mlo-group/1# **enabled true** (enable MLO group)
WEP-550K(config):/mlo/mlo-group/1# **save** (save settings)

6.4.2 Configuring MLO Group with WPA-Personal security mode

Creating an MLO group with WPA3-Personal security mode

WEP-550K(root):/# **configure**
WEP-550K(config):/# **mlo**
WEP-550K(config):/mlo# **mlo-group**
WEP-550K(config):/mlo/mlo-group# **1**
WEP-550K(config):/mlo/mlo-group/1# **ssid SSID_WEP-550K_MLO_Wpa3** (change SSID name)
WEP-550K(config):/mlo/mlo-group/1# **ap-security**
WEP-550K(config):/mlo/mlo-group/1/ap-security# **mode WPA3** (encryption mode — WPA3)
WEP-550K(config):/mlo/mlo-group/1/ap-security# **key-wpa password123** (key/password, required to connect to the virtual access point. The key length must be from 8 to 63 characters)
WEP-550K(config):/mlo/mlo-group/1/ap-security# **exit**
WEP-550K(config):/mlo/mlo-group/1# **enabled true** (enable MLO group)
WEP-550K(config):/mlo/mlo-group/1# **save** (save settings)

6.4.3 Configuring MLO Group with Enterprise authorization

Creating an MLO group with WPA3-Enterprise security mode

WEP-550K(root):/# **configure**
WEP-550K(config):/# **mlo**
WEP-550K(config):/mlo# **mlo-group**
WEP-550K(config):/mlo/mlo-group# **1**
WEP-550K(config):/mlo/mlo-group/1# **ssid SSID_WEP-550K_MLO_Wpa3E** (change SSID name)
WEP-550K(config):/mlo/mlo-group/1# **ap-security**
WEP-550K(config):/mlo/mlo-group/1/ap-security# **mode WPA3_1X** (encryption mode — WPA3-Enterprise)
WEP-550K(config):/mlo/mlo-group/1/ap-security# **exit**
WEP-550K(config):/mlo/mlo-group/1# **radius**
WEP-550K(config):/mlo/mlo-group/1/radius# **auth-address X.X.X.X** (where X.X.X.X is the IP address of the RADIUS server)
WEP-550K(config):/mlo/mlo-group/1/radius# **auth-port X** (where X is the port of the RADIUS server, which is used for authentication and authorization. By default: 1812)
WEP-550K(config):/mlo/mlo-group/1/radius# **auth-password secret** (where secret is the password for the RADIUS server used for authentication and authorization)
WEP-550K(config):/mlo/mlo-group/1/radius# **exit**
WEP-550K(config):/mlo/mlo-group/1# **enabled true** (enable MLO group)
WEP-550K(config):/mlo/mlo-group/1# **save**

6.4.4 Advanced MLO settings

Configuring VLAN ID for MLO group

WEP-550K(config):/mlo/mlo-group/1# **vlan-id X** (where X — VLAN ID number for MLO group)

6.5 Configuring AirTune

Configuring AirTune

WEP-550K(config):/# **airtune**
WEP-550K(config):/airtune# **airtune_service_url ws://192.168.1.20:8099/apb/rrm** (where 192.168.1.20 is the IP address of the server where the AirTune service is set)
WEP-550K(config):/airtune# **enabled true** (enable interaction with the AirTune service. To disable, enter **false**)
WEP-550K(config):/airtune# **save** (save settings)

To enable automatic 802.11r configuration via the AirTune service on the access point, enable the 802.11r function. To do this, perform the following settings:

Configuring 802.11r via AirTune

WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **enabled true** (enable access point operation via protocol 802.11r)
WEP-550K(config):/interface/wlan1-vap0/vap/ft-config# **save** (save settings)

To enable automatic 802.11k/v configuration via the AirTune service on the access point, enable the 802.11k/v function on the SSID. To do this, perform the following settings:

Configuring 802.11k/v via AirTune

WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **enabled true** (enable support for protocol 802.11k/v on the virtual access point)
WEP-550K(config):/interface/wlan1-vap0/vap/w80211kv-config# **save** (save settings)

The configuration of the AirTune service is described in the SoftWLC controller documentation.

6.6 Radio settings

By default, Radio uses automatic operating channel selection. To set the channel manually or change the power, use the following commands:

Changing the working channel and power of the radio interface

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan0**
WEP-550K(config):/interface/wlan0# **wlan**
WEP-550K(config):/interface/wlan0/wlan# **radio**
WEP-550K(config):/interface/wlan0/wlan/radio# **channel X** (where X is the number of the static channel on which the access point will operate)
WEP-550K(config):/interface/wlan0/wlan/radio# **auto-channel false** (disable automatic channel selection. To enable, enter **true**)
WEP-550K(config):/interface/wlan0/wlan/radio# **use-limit-channels false** (disable the use of the limited channel list. To enable, enter **true**)
WEP-550K(config):/interface/wlan0/wlan/radio# **bandwidth X** (where X is the channel width. The parameter can take the following values: for Radio 1: 20, 40; Radio 2: 20, 40, 80)
WEP-550K(config):/interface/wlan0/wlan/radio# **tx-power X** (where X is the power level in dBm. The parameter can take the following values: for Radio 1: 0–16 dBm; for Radio 2: 0–19 dBm)
WEP-550K(config):/interface/wlan0/wlan/radio# **save** (save settings)

Lists of available channels

The following channels are available for Radio 2.4 GHz:

- when the channel width is 20 MHz: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13.
- when the channel width is 40 MHz:
  - if "control-sideband" = lower: 1, 2, 3, 4, 5, 6, 7, 8, 9.
  - if "control-sideband" = upper: 5, 6, 7, 8, 9, 10, 11, 12, 13.

The following channels are available for Radio 5 GHz:

- when the channel width is 20 MHz: 36, 40, 44, 48, 52, 56, 60, 64, 132, 136, 140, 144, 149, 153, 157, 161, 165.
- when the channel width is 40 MHz:
  - if "control-sideband" = lower: 36, 44, 52, 60, 132, 140, 149, 157.
  - if "control-sideband" = upper: 40, 48, 56, 64, 136, 144, 153, 161.
- when the channel width is 80 MHz: 36, 40, 44, 48, 52, 56, 60, 64, 132, 136, 140, 144, 149, 153, 157, 161.
- when the channel width is 160 MHz: 36, 40, 44, 48, 52, 56, 60, 64.

The following channels are available for Radio 6 GHz:

- when the channel width is 20 MHz: 1, 5, 9, 13, 17, 21, 25, 29, 33, 37, 41, 45, 49, 53, 57, 61, 65, 69, 73, 77, 81, 85, 89, 93.
- when the channel width is 40 MHz:
  - if "control-sideband" = lower: 1, 9, 17, 25, 33, 41, 49, 57, 65, 73, 81, 89.
  - if "control-sideband" = upper: 5, 13, 21, 29, 37, 45, 53, 61, 69, 77, 85, 93.
- when the channel width is 80/160 MHz: 1, 5, 9, 13, 17, 21, 25, 29, 33, 37, 41, 45, 49, 53, 57, 61, 65, 69, 73, 77, 81, 85, 89, 93.
- when the channel width is 320 MHz:
  - if "control-sideband" = lower: 1, 5, 9, 13, 17, 21, 25, 29, 33, 37, 41, 45, 49, 53, 57, 61.
  - if "control-sideband" = upper: 33, 37, 41, 45, 49, 53, 57, 61, 65, 69, 73, 77, 81, 85, 89, 93.

6.6.1 Advanced Radio settings

Configuring a limited channel list

WEP-550K(config):/interface/wlan0/wlan/radio# **use-limit-channels true** (enable the use of the limited channel list in automatic channel selection operation. To disable, enter **false**. By default: true)
WEP-550K(config):/interface/wlan0/wlan/radio# **limit-channels '1 6 11'** (where 1, 6, 11 are the channels of the band in which the configurable radio interface can operate)

Changing the primary channel

WEP-550K(config):/interface/wlan0/wlan/radio# **control-sideband lower** (parameter can take the following values: **lower**, **upper**. By default: for Radio 1: lower; for Radio 2: upper)

Enabling use of short guard interval

WEP-550K(config):/interface/wlan0/wlan/radio# **sgi true** (enable the use of the shortened guard interval for data transmission — 400 ns, instead of 800 ns. To disable, enter **false**)

Enabling STBC

WEP-550K(config):/interface/wlan0/wlan/radio# **stbc true** (enable the space-time block coding (STBC) method, designed to improve data transmission reliability. To disable, enter **false**)

Enabling the use of short preamble

WEP-550K(config):/interface/wlan0/wlan/radio# **short-preamble true** (enable the use of the packet short preamble. To disable, enter **false**)

Enabling Wi-Fi Multimedia (WMM)

WEP-550K(config):/interface/wlan0/wlan/radio# **wmm true** (enable WMM (Wi-Fi Multimedia) support. To disable, enter **false**)

Configuring the DFS mechanism

Configuration is performed only on Radio 5 GHz (wlan1)

WEP-550K(config):/interface/wlan1/wlan/radio# **dfs X** (where X is the operating mode of the DFS mechanism. Possible values: **forced** — mechanism is disabled, DFS channels are available for selection; **auto** — mechanism is enabled; **disabled** — mechanism is disabled, DFS channels are not available for selection)

Enabling automatic channel width change mode

WEP-550K(config):/interface/wlan0/wlan/radio# **obss-coex true** (enable automatic channel width change mode from 40 MHz to 20 MHz when the radio environment is congested. To disable, enter **false**)

6.7 Configuring DHCP option 82

DHCP option 82 is configured separately for each radio interface. This section provides examples of configuring option 82 for Radio 2.4 GHz — wlan0.

DHCP snooping operating modes:

- **ignore** – option 82 processing is disabled. Default value;
- **replace** – access point substitutes or replaces the value of option 82;
- **remove** – access point removes the value of option 82.

Changing the operating mode of DHCP option 82

WEP-550K(root):/# **configure**
WEP-550K(config):/# **interface**
WEP-550K(config):/interface# **wlan0** (configuring will be done for Radio 2.4 GHz. To configure option 82 on Radio 5 GHz or Radio 6 GHz, enter **wlan1** or **wlan2** respectively)
WEP-550K(config):/interface/wlan0# **common**
WEP-550K(config):/interface/wlan0/common# **dhcp-snooping**
WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **dhcp-snooping-mode replace** (selection of DHCP snooping operation in the mode of replacement or substitution of option 82)
WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **save** (save changes)

If on the radio interface the 82 option processing policy is configured to **replace**, the following parameters become available for configuration:

Configuring Option 82 parameters

WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **dhcp-option-82-CID-format custom** (where **custom** — replacement of the CID content with the value specified in the **dhcp-option-82-custom-CID** parameter. The parameter can take values: **APMAC-SSID** — replacement of the CID content with <MAC address of the access point>-<SSID name>. **SSID** — replacement of the CID content with SSID name, to which the client is connected. By default: **APMAC-SSID**)
WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **dhcp-option-82-RID-format custom** (where **custom** — replacement of the RID content with the value specified in the **dhcp-option-82-custom-RID** parameter. The parameter can take values: **ClientMAC** — replacement of the RID content with MAC address of the client device. **APMAC** — replacement of the RID content with MAC address of the access point**. APdomain** — replacement of the RID content with the domain where the access point is located. By default: **ClientMAC**)
WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **dhcp-option-82-custom-CID longstring** (where **longstring** — value from 1 to 52 characters, which will be transmitted in CID. If the value of **dhcp-option-82-custom-CID** parameter is not defined, the access point will change the CID to the default value: <MAC address of the access point>-<SSID name>)
WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **dhcp-option-82-custom-RID longstring** (where **longstring** — value from 1 to 63 characters, which will be transmitted in RID. If the value of **dhcp-option-82-custom-RID** parameter is not defined, the access point will change the RID to the default value: MAC address of the client device)
WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **dhcp-option-82-MAC-format radius** (selecting octet delimiter of the MAC address which is transmitted in RID and CID. **radius** — a dash is used as a delimiter: AA-BB-CC-DD-EE-FF; **default** — a colon is used as a delimiter: AA:BB:CC:DD:EE:FF)
WEP-550K(config):/interface/wlan0/common/dhcp-snooping# **save** (save changes)

6.8 System settings

6.8.1 Device firmware update

Firmware upgrade of access points via tftp

WEP-550K(root):/# **firmware upload tftp <IP Address of TFTP server> <Firmware file name>** (example: firmware upload tftp 192.168.1.15 WEP-550K-1.4.2_build_X.tar.gz)
WEP-550K(root):/# **firmware upgrade**

Firmware upgrade of access points via http

WEP-550K(root):/# **firmware upload http <URL to download the firmware file>** (example: firmware upload http http://192.168.1.100:8080/files/WEP-550K-1.4.2_build_X.tar.gz)
WEP-550K(root):/# **firmware upgrade**

Switching to access point backup firmware

WEP-550K(root):/# **firmware switch**

6.8.2 Device configuration management

Reset device configuration to default without saving access parameters

WEP-550K(root):/# **manage-config reset-to-default**

Reset device configuration to default with preserving access parameters

WEP-550K(root):/# **manage-config reset-to-default-without-management**

Download the device configuration file to a TFTP server

WEP-550K(root):/# **manage-config download tftp <IP Address of TFTP server>** (example: manage-config download tftp 192.168.1.15)

Download device configuration file to server/PC via SCP

scp <user>@<IP Address device>:/etc/config/config.json config.json (example: scp admin@192.168.1.15:/etc/config/config.json config.json. This command is performed on the server/PC)

Upload a configuration file to the device from a TFTP server

WEP-550K(root):/# **manage-config upload tftp <IP Address of TFTP server> <Configuration file name>** (example: manage-config upload tftp 192.168.1.15 config.json)
WEP-550K(root):/# **manage-config apply** (apply configuration on the access point)

6.8.3 Device reboot

Command for rebooting the device

WEP-550K(root):/# **reboot**

6.8.4 Configuring the authentication mode

The device has a factory user account of *admin* with password of *password*. This account cannot be deleted. The password can be changed using the commands specified below.

Changing the password for the admin account

WEP-550K(root):/# **configure**
WEP-550K(config):/# **authentication**
WEP-550K(config):/authentication# **admin-password <new password for the admin account>** (from 1 to 64 characters, including Latin letters and digits)
WEP-550K(config):/authentication# **save**

6.8.5 Setting the date and time

Commands for configuring time synchronization with an NTP server

WEP-550K(root):/# **configure**
WEP-550K(config):/# **date-time**
WEP-550K(config):/date-time# **mode ntp** (enable NTP mode)
WEP-550K(config):/date-time# **ntp**
WEP-550K(config):/date-time/ntp# **server <IP address of the NTP server>** (set the NTP server)
WEP-550K(config):/date-time/ntp# **alt-servers** (set additional NTP servers)
WEP-550K(config):/date-time/ntp/alt-servers# **add <domain name/IP address of the NTP server in the configuration>** (create a configuration section for an additional NTP server. Maximum number: 8. To delete, use the command **del**)
WEP-550K(config):/date-time/ntp/alt-servers# **exit**
WEP-550K(config):/date-time/ntp# **exit**
WEP-550K(config):/date-time# **common**
WEP-550K(config):/date-time/common# **timezone 'Asia/Novosibirsk (Novosibirsk)'** (set the time zone)
WEP-550K(config):/date-time/common# **save** (save settings)

6.8.6 Advanced system settings

Changing the device name

WEP-550K(root):/# **configure**
WEP-550K(config):/# **system**
WEP-550K(config):/system# **hostname WEP-550K_room2** (where WEP-550K_room2 is a new device name. The parameter can accept values from 1 to 63 characters: capital and lowercase Latin letters, digits, hyphen character "-" (hyphen can not be the last character in name). By default: WEP-550K)
WEP-550K(config):/system# **save** (save settings)

Changing geographical domain

WEP-550K(root):/# **configure**
WEP-550K(config):/# **system**
WEP-550K(config):/system# **ap-location ap.test.root** (where ap.test.root is the domain of the device tree node of the EMS management system in which the access point is located. By default: root)
WEP-550K(config):/system# **save** (save settings)

Changing Radius NAS-ID

WEP-550K(root):/# **configure**
WEP-550K(config):/# **system**
WEP-550K(config):/system# **nas-id Lenina_1.Novovsibirsk.root** (where Lenina_1.Novovsibirsk.root is the identifier of this access point. The parameter is intended to identify the device on the RADIUS server if RADIUS expects a value other than the MAC address. By default: MAC address of the access point)
WEP-550K(config):/system# **save** (save settings)

Configuring LLDP

WEP-550K(root):/# **configure**
WEP-550K(config):/# **lldp**
WEP-550K(config):/lldp# **enabled true** (enable the LLDP functionality. To disable, enter **false**. By default: true)
WEP-550K(config):/lldp# **tx-interval 60** (changing the period for sending LLDP messages. By default: 30)
WEP-550K(config):/lldp# **system-name WEP-550K_reserv** (where WEP-550K_reserv is a new device name. By default: WEP-550K)
WEP-550K(config):/lldp# **save** (save settings)

6.9 Configuring Captive Portal parameters

Configuring the parameter names passed by the authorization web server

WEP-550K(root):/# **configure**
WEP-550K(config):/# **captive-portal**
WEP-550K(config):/captive-portal# **web-redirector**
WEP-550K(config):/captive-portal/web-redirector# **param-names**
WEP-550K(config):/captive-portal/web-redirector/param-names# **redirect_url original_url** (set the name of the parameter containing the original URL requested by the client. The client will be redirected to this URL if the authorization is successful)
WEP-550K(config):/captive-portal/web-redirector/param-names# **error_url err_url** (set the name of the parameter containing the URL where the client will be redirected in case of an authorization error)
WEP-550K(config):/captive-portal/web-redirector/param-names# **username login** (set the name of the parameter containing the login for the client)
WEP-550K(config):/captive-portal/web-redirector/param-names# **password pass** (set the name of the parameter containing the password for the client)
WEP-550K(config):/captive-portal/web-redirector/param-names# **save** (save settings)

The setting is needed if the parameter names in the http response with code 302 differ from the default names accepted by the access point.

In the values of the **redirect_url**, **error_url**, **username**, **password** parameters, only the following characters can be used [a-zA-Z0-9$\-_.!*'(),]{0,255}

Configuring the adaptive captive portal mode

WEP-550K(root):/# **configure**
WEP-550K(config):/# **captive-portal**
WEP-550K(config):/captive-portal# **web-redirector**
WEP-550K(config):/captive-portal/web-redirector# **captive-adaptive true** (enable the adaptive captive portal mode for iOS devices. To disable, enter **false**. By default: false)
WEP-550K(config):/captive-portal/web-redirector# **save** (save settings)

With the adaptive mode enabled, the connection will not be dropped when the authorization window is minimized on iOS devices.

Configuring ipv4-acl rules

WEP-550K(root):/# **configure**
WEP-550K(config):/# **acl**
WEP-550K(config):/acl# **ipv4**
WEP-550K(config):/acl/ipv4# **add ipv4_list** (create an ACL rule list)
WEP-550K(config):/acl/ipv4#**ipv4_list**
WEP-550K(config):/acl/ipv4/ipv4_list# **entry**
WEP-550K(config):/acl/ipv4/ipv4_list/entry# **add 0** (create an ACL rule)
WEP-550K(config):/acl/ipv4/ipv4_list/entry# **0**
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **action permit** (specify the action for the rule. Possible values: **permit** — allow, **deny** — deny)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **protocol-mode any** (configure the protocol mode that the rule applies to. Possible values: **any** — any protocol, **value** — specific protocol)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **protocol gre** (select the protocol. Possible values: **gre**, **icmp**, **igmp**, **tcp**, **udp**)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **src-port-start X** (where X is the starting source port)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **src-port-end X** (where X is the ending source port. Used only for src-port-mode range)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **src-mode host** (configure the source filtering mode. Possible values: **any** — any source, **host** — filtering by host address, **network** — filtering by network address)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **src-ip X.X.X.X** (where X.X.X.X is the source host IP address)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **src-mask X.X.X.X** (where X.X.X.X is the source host subnet mask)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **src-port-mode any** (configure the source port mode. Possible values: **any** — any mode, **eq** — equal, **gt** — greater than, **lt** — less than, **neq** — not equal, **range** — port range)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **dst-mode host** (configure the destination filtering mode. Possible values: **any** — any source, **host** — filtering by host address, **network** — filtering by network address)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **dst-ip X.X.X.X** (where X.X.X.X is the destination host IP address)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **dst-mask X.X.X.X** (where X.X.X.X is the destination host subnet mask)
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **dst-port-mode any** (configure the destination port mode. Possible values: **any** — any mode, **eq** — equal, **gt** — greater, **lt** — less, **neq** — not equal, **range** — port range))
WEP-550K(config):/acl/ipv4/ipv4_list/entry/0# **dst-port-start X** (where X is the starting destination port)
WEP-550K(config):/acl/ipv4/ipv4-acl/ipv4_list/entry/0# **dst-port-end X** (where X is the ending destination port. Used only for dst-port-mode range)
WEP-550K(config):/acl/ipv4/ipv4-acl/ipv4_list/entry/0# **save** (save settings)

Configuring url-acl rules

WEP-550K(root):/# **configure**
WEP-550K(config):/# **acl**
WEP-550K(config):/acl# **url**
WEP-550K(config):/acl/url# **add url_list** (create an ACL rule list)
WEP-550K(config):/acl/url# **url_list**
WEP-550K(config):/acl/url/url_list# **action permit** (specify the action for the list. Possible values: **permit** — allow, **deny** — deny)
WEP-550K(config):/acl/url/url_list# **entry**
WEP-550K(config):/acl/url/url_list/entry# **add 0** (create an ACL rule)
WEP-550K(config):/acl/url/url_list/entry# **0**
WEP-550K(config):/acl/url/url_list/entry/0# **domain <Domain name>** (specify a domain name or a regular expression)
WEP-550K(config):/acl/url/url_list/entry/0# **save** (save settings)

6.10 Configuring DAS server

The DAS server function processes dynamic RADIUS authorization requests from access points.

Commands for configuring the DAS server

WEP-550K(root):/# **configure**
WEP-550K(config):/# **das-server**
WEP-550K(config):/das-server# **enabled true** (enable the DAS server. To disable, enter **false**)
WEP-550K(config):/das-server# **auth-password secret** (where secret — is the DAS server password, used to encrypt RADIUS requests)
WEP-550K(config):/das-server# **save** (save settings)

6.11 Configuring multiple controller addresses

Commands for configuring multiple controller addresses

WEP-550K(root):/# **configure**
WEP-550K(config):/# **service-activator**
WEP-550K(config):/service-activator# **wlc**
WEP-550K(config):/service-activator/wlc# **keepalive 120** (timeout for connecting to the controller. After the timeout expires, an attempt will be made to connect to the next controller in the list. Possible values: [30..32767]. By default: 120)
WEP-550K(config):/service-activator/wlc# **options**
WEP-550K(config):/service-activator/wlc/options# **try-switch-to-master-wlc true** (enable periodic attempts to connect to the first controller from the list. To disable enter **false**. By default: false)
WEP-550K(config):/service-activator/wlc/options# **require-date-time-sync true** (enable time synchronization from the controller via NTP before attempting to connect. To disable enter **false**. By default: false)
WEP-550K(config):/service-activator/wlc/options# **exit**
WEP-550K(config):/service-activator/wlc# **wlc-connections-info**
WEP-550K(config):/service-activator/wlc/wlc-connections-info# **add name** (create a configuration block for connecting to the controller. It is possible to add multiple settings blocks. To delete enter **del**)
WEP-550K(config):/service-activator/wlc/wlc-connections-info# **name** (move to block)
WEP-550K(config):/service-activator/wlc/wlc-connections-info/name# **wlc-url <WLC controller address>** (example: https://192.168.1.20:8043)
WEP-550K(config):/service-activator/wlc/wlc-connections-info/name# **user-gre-addr X.X.X.X** (where X.X.X.X — controller IP address for user-gre tunnel termination)
WEP-550K(config):/service-activator/wlc/wlc-connections-info/name# **save** (save settings)

6.12 Passive radio environment scanning manager configuration

To enable continuous scanning on the access point, configure the passive scanning manager “scand“.

Commands for configuring scand

WEP-550K(root):/# **configure**
WEP-550K(config):/# **scand**
WEP-550K(config):/scand# **neighbor-scan**
WEP-550K(config):/scand/neighbor-scan# **neighbor-scan-enabled true** (enable continuous scanning. To disable, enter **false**)
WEP-550K(config):/scand/neighbor-scan# **save** (save settings)

6.13 Monitoring

6.13.1 Wi-Fi clients

WEP-550K(root):/# **monitoring associated-clients**

```
index                              | 0
ssid                               | Virtual Access Point 0 (6GHz)
hw-addr                            | 0a:a5:08:xx:xx:xx
ip-addr                            | 192.168.1.15
hostname                           | client
domain                             | root
authenticated                      | yes
associated                         | yes
authorized                         | yes
captive-portal-vap                 | no
enterprise-vap                     | no
band                               | 6
tx-fails                           | 14
link-capacity                      | 100%
link-quality                       | 100%
uptime                             | 00:12:05
interface                          | wlan2-vap0
rfid                               | 2
wid                                | 0
tx-bw                              | 320M
rx-bw                              | 320M
rx-bw-all                          | 320M
rssi-1                             | -41
rssi-2                             | -42
rssi-3                             | -47
rssi                               | -47
snr-1                              | 53
snr-2                              | 54
snr-3                              | 54
snr                                | 53
mfp                                | yes
tx-rate                            | EHT NSS2-MCS10 ?xLTF GI 0.8us 4322
rx-rate                            | EHT NSS2-MCS12 ?xLTF GI 0.8us 5188
tx-retry-count                     | 14
rx-retry-count                     | 1156
tx-period-retry                    | 0
using-802.11r                      | no
using-802.11k                      | no
using-802.11v                      | no
wireless-mode                      | be
mlo-enabled                        | yes
name                               | wlan2-vap0:sta-0
mld-mac                            | 18:2b:3c:4d:5e:6f
mld-mac-ap                         | e0:f3:4a:5b:6c:7d
mlo-link-1--------------------------|
mlo-link-1-band                    | 2
mlo-link-1-bandwidth               | 40M
mlo-link-1-mac                     | 1a:2b:3c:4d:5e:6f
mlo-link-1-bssid                   | e2:f3:4a:5b:6c:7d
mlo-link-1-rssi-1                  | -27
mlo-link-1-rssi-2                  | -32
```

```
mlo-link-1-snr-1                    | 53
mlo-link-1-snr-2                    | 52
mlo-link-1-tx-rate                  | DSSS  1
mlo-link-1-rx-rate                  | OFDM  6
mlo-link-1-bytes-tx                 | 0
mlo-link-1-bytes-rx                 | 800
mlo-link-1-packets-tx               | 3
mlo-link-1-packets-rx               | 663
mlo-link-1-errors-tx                | 0
mlo-link-1-retries                  | 0
mlo-link-1-air-time-tx              | 0
mlo-link-1-air-time-rx              | 1974

mlo-link-2--------------------------|
mlo-link-2-band                     | 5
mlo-link-2-bandwidth                | 160M
mlo-link-2-mac                      | 1a:2b:3c:4d:5e:7f
mlo-link-2-bssid                    | e2:f3:4a:5b:6c:8d
mlo-link-2-rssi-1                   | -40
mlo-link-2-rssi-2                   | -40
mlo-link-2-rssi-3                   | -44
mlo-link-2-snr-1                    | 56
mlo-link-2-snr-2                    | 56
mlo-link-2-snr-3                    | 55
mlo-link-2-tx-rate                  | EHT NSS3-MCS0 ?xLTF GI 0.8us 25
mlo-link-2-rx-rate                  | EHT NSS3-MCS10 ?xLTF GI 0.8us 387
mlo-link-2-bytes-tx                 | 160
mlo-link-2-bytes-rx                 | 26688
mlo-link-2-packets-tx               | 2
mlo-link-2-packets-rx               | 0
mlo-link-2-errors-tx                | 0
mlo-link-2-retries                  | 0
mlo-link-2-air-time-tx              | 5608
mlo-link-2-air-time-rx              | 172408

mlo-link-3--------------------------|
mlo-link-3-band                     | 6
mlo-link-3-bandwidth                | 320M
mlo-link-3-mac                      | 1a:2b:3c:4d:5e:8f
mlo-link-3-bssid                    | e2:f3:4a:5b:6c:9d
mlo-link-3-rssi-1                   | -41
mlo-link-3-rssi-2                   | -42
mlo-link-3-rssi-3                   | -47
mlo-link-3-snr-1                    | 53
mlo-link-3-snr-2                    | 54
mlo-link-3-snr-3                    | 54
mlo-link-3-tx-rate                  | EHT NSS3-MCS0 ?xLTF GI 0.8us 216
mlo-link-3-rx-rate                  | EHT NSS3-MCS10 ?xLTF GI 0.8us 3242
mlo-link-3-bytes-tx                 | 832
mlo-link-3-bytes-rx                 | 1760
mlo-link-3-packets-tx               | 0
mlo-link-3-packets-rx               | 0
mlo-link-3-errors-tx                | 0
mlo-link-3-retries                  | 0
mlo-link-3-air-time-tx              | 40939
mlo-link-3-air-time-rx              | 6303
```

```
Counter                 Transmitted              Received
----------------------  -----------------------  -------------------------
Total Packets:          7110                     9168
TX success:             100
Total Bytes:            5454016                  1939584
Data Packets:           0                        4263
Data Bytes:             0                        1169546
Mgmt Packets:           7                        32
Mgmt Bytes:             0                        0
Dropped Packets:        0                        0
Dropped Bytes:          0                        0
Lost Packets:           0

Multicast groups: none
```

6.13.2 Device information

WEP-550K(root):/# **monitoring information**

```
system-time                  | 07:54:17 13.05.2026
uptime                       | 00:01:42
hostname                     | WEP-550K
software-version             | 1.4.2 build X
secondary-software-version   | 1.4.2 build X
boot-version                 | 1.4.2 build X
uboot-version                | 1.4.2 build X
memory-usage                 | 52%
memory-free                  | 466M
memory-used                  | 515M
memory-total                 | 981M
cpu-load                     | 2.9%
cpu-average                  | 2.30%
is-default-config            | true
vendor                       | Eltex
device-type                  | Access Point
board-type                   | WEP-550K
hw-platform                  | WEP-550K
factory-wan-mac              | 0C:EE:20:xx:xx:xx
factory-lan-mac              | 0C:EE:20:xx:xx:xx
factory-serial-number        | WPxxxxxxxx
hw-revision                  | 1v2
session-password-initialized | false
ott-mode                     | false
last-reboot-reason           | reboot by user
test-changes-mode            | false
power-supply                 | PoE++
```

6.13.3 Network information

WEP-550K(root):/# **monitoring wan-status**

```
Common information:

 interface                | br0
 mac                      | 0c:ee:20:xx:xx:xx
 rx-bytes                 | 456875
 rx-packets               | 5835
 tx-bytes                 | 24328
 tx-packets               | 241

IPv4 information:

 protocol                 | dhcp
 ip-address               | 192.168.1.15
 netmask                  | 255.255.255.0
 gateway                  | 192.168.1.1
 DNS-1                    | 192.168.1.100
 DNS-2                    | 8.8.8.8
```

WEP-550K(root):/# **monitoring ethernet-ports**

```
   ETH0:
      name: ETH0
      link: up
      speed: 1000
      duplex: enabled
      media-type: copper
      rx-bytes: 69952
      rx-packets: 662
      tx-bytes: 22397
      tx-packets: 143
   ETH1:
      name: ETH1
      link: down
      speed: 10
      duplex: disabled
      media-type: copper
      rx-bytes: 0
      rx-packets: 0
      tx-bytes: 0
      tx-packets: 0
```

WEP-550K(root):/# **monitoring arp**

```
#        ip               mac
-------------------------------------------
0        192.168.1.1      02:00:48:xx:xx:xx
1        192.168.1.151    2c:fd:a1:xx:xx:xx
```

WEP-550K(root):/# **monitoring route**

```
Destination       Gateway           Mask              Flags      Interface
-------------------------------------------------------------------------
0.0.0.0           192.168.1.1       0.0.0.0           UG         br0
192.168.1.0       0.0.0.0           255.255.255.0     U          br0
```

WEP-550K(root):/# **monitoring lldp**

```
System capability legend:
        B - Bridge; R - Router; W - Wlan Access Point; T - Telephone;
        D - DOCSIS Cable Device; H - Host; r - Repeater; O - Other;

Port        Device ID           Port ID       System Name     Capabilities   TTL
---------   -----------------   -----------   -------------   ------------   ---
eth0        e0:d9:e3:xx:xx:xx   gi 0/16       MES             B,R            120
```

6.13.4 Wireless interfaces

WEP-550K(root):/# **monitoring radio-interface**

```
name                    | wlan0
rfid                    | 0
status                  | on
band                    | 2.4 GHz
hwaddr                  | 0C:EE:20:xx:xx:xx
tx-power                | 15 dBm
connection status       | AP mode
operation mode          | vap
mode                    | b/g/n/ax/be
noise-1                 | -77 dBm
noise-2                 | -78 dBm
channel                 | 6
frequency               | 2437 MHz
bandwidth               | 20 MHz
utilization             | 5%
thermal                 | 41

name                    | wlan1
rfid                    | 1
status                  | on
band                    | 5 GHz
hwaddr                  | 0C:EE:20:xx:xx:xx
tx-power                | 19 dBm
connection status       | AP mode
operation mode          | vap
mode                    | a/n/ac/ax/be
noise-1                 | -91 dBm
noise-2                 | -91 dBm
noise-3                 | -92 dBm
channel                 | 36
frequency               | 5180 MHz
bandwidth               | 20 MHz
utilization             | 1%
thermal                 | 40

name                    | wlan2
rfid                    | 2
status                  | on
band                    | 6 GHz
hwaddr                  | 0C:EE:20:xx:xx:xx
tx-power                | 19 dBm
connection status       | AP mode
operation mode          | vap
mode                    | ax/be
noise-1                 | -92 dBm
noise-2                 | -92 dBm
noise-3                 | -92 dBm
channel                 | 1
frequency               | 5955 MHz
bandwidth               | 20 MHz
utilization             | 0%
thermal                 | 45
```

6.13.5 Event logging

WEP-550K(root):/# **monitoring events**

```
Jan  1 00:00:36 WEP-550K user.notice root: The AP startup configuration was updated
successfully by root
Jan  1 00:00:36 WEP-550K daemon.info networkd[4442]: DHCP-client: Interface br0 obtained
lease on 192.168.1.15.
Oct 1 06:03:13 WEP-550K daemon.info configd[4390]: The AP running configuration was updated
successfully by admin
Oct 1 06:08:42 WEP-550K auth.info login[24431]: root login on 'pts/0'
Oct 1 06:16:41 WEP-550K daemon.info hostapd: wlan0-vap2: STA 16:40:ee:xx:xx:xx IEEE 802.11:
associated
Oct 1 06:16:41 WEP-550K daemon.info hostapd: Client '16:40:ee:xx:xx:xx' successfull
authorized with 'wlan0-vap2', SSID 'eltex', Domain '', RSSI '-34'
```

6.13.6 Environment scan

While scanning the environment, the device radio interface will be disabled, which will make it impossible to transfer data to Wi-Fi clients during scanning.

Active environment scan

WEP-550K(root):/#**monitoring scan-wifi**

SSID	Mode	Security	BSSID	Channel	RSSI, dBm	Bandwidth, MHz
[redacted]	AP	off	[redacted]	6	-37	20
[redacted]	AP	wpa2	[redacted]	9	-51	40L
[redacted]	AP	wpa2	[redacted]	1	-54	20
[redacted]	AP	wpa2	[redacted]	11	-61	20
[redacted]	AP	off	[redacted]	6	-62	40L
[redacted]	AP	off	[redacted]	6	-62	40L
[redacted]	AP	wpa/wpa2	[redacted]	2	-79	40L
[redacted]	AP	off	[redacted]	149	-79	80
[redacted]	AP	off	[redacted]	48	-79	20
[redacted]	AP	off	[redacted]	52	-79	20
[redacted]	AP	wpa2	[redacted]	40	-79	20
[redacted]	AP	wpa/wpa2	[redacted]	11	-79	20
[redacted]	AP	off	[redacted]	11	-80	20
[redacted]	AP	wpa2-1x	[redacted]	11	-80	20
[redacted]	AP	off	[redacted]	1	-81	20
[redacted]	AP	wpa3-1x	[redacted]	77	-81	20
[redacted]	AP	wpa2-1x	[redacted]	1	-82	20
[redacted]	AP	off	[redacted]	64	-82	160
[redacted]	AP	wpa2	[redacted]	11	-82	20
[redacted]	AP	wpa2	[redacted]	11	-82	20
[redacted]	AP	owe	[redacted]	64	-83	160
[redacted]	AP	wpa2-1x	[redacted]	64	-83	80
[redacted]	AP	wpa3	[redacted]	53	-83	320L

Passive environment scan

First, enable the passive radio environment scanning manager.

WEP-550K(root):/# **monitoring neighbor-ap**

SSID	Security Mode	BSSID	Channel	RSSI, dBm	Bandwidth, MHz	Last seen time
[redacted]	Open	[redacted]	1	-38	20	2025.10.29 12:26:42
[redacted]	OWE	[redacted]	1	-74	20	2025.10.29 12:26:42
[redacted]	WPA2	[redacted]	5	-73	20	2025.10.29 12:30:10
[redacted]	WPA/WPA2	[redacted]	6	-57	20	2025.10.29 12:30:30
[redacted]	WPA3	[redacted]	6	-58	20	2025.10.29 12:30:30
[redacted]	WPA3_1X	[redacted]	9	-59	40	2025.10.29 12:32:14
[redacted]	WPA2	[redacted]	9	-70	40	2025.10.29 12:32:14
[redacted]	WPA3	[redacted]	9	-63	40	2025.10.29 12:32:14
[redacted]	WPA2_1X	[redacted]	11	-63	20	2025.10.29 12:33:36
[redacted]	Open	[redacted]	36	-67	20	2025.10.29 12:34:37
[redacted]	WPA2/WPA3	[redacted]	36	-67	20	2025.10.29 12:34:37
[redacted]	WPA3	[redacted]	36	-52	80	2025.10.29 12:34:37
[redacted]	Open	[redacted]	36	-54	40	2025.10.29 12:34:37
[redacted]	Open	[redacted]	40	-67	20	2025.10.29 12:27:03
[redacted]	WPA2/WPA3	[redacted]	40	-68	20	2025.10.29 12:27:03
[redacted]	WPA2_1X	[redacted]	44	-61	20	2025.10.29 12:27:23
[redacted]	WPA2	[redacted]	48	-74	80	2025.10.29 12:27:44
[redacted]	Open	[redacted]	48	-74	80	2025.10.29 12:27:44
[redacted]	Open	[redacted]	52	-59	40	2025.10.29 12:28:05
[redacted]	WPA2_1X	[redacted]	56	-61	20	2025.10.29 12:28:25
[redacted]	WPA2_1X	[redacted]	60	-39	80	2025.10.29 12:28:46
[redacted]	WPA2_1X	[redacted]	60	-59	20	2025.10.29 12:28:46
[redacted]	WPA/WPA2	[redacted]	60	-59	80	2025.10.29 12:28:46
[redacted]	WPA2	[redacted]	64	-62	40	2025.10.29 12:29:07
[redacted]	WPA2_1X	[redacted]	64	-64	20	2025.10.29 12:29:07
[redacted]	WPA2_1X	[redacted]	132	-47	40	2025.10.29 12:29:27
[redacted]	WPA2	[redacted]	132	-47	40	2025.10.29 12:29:27
[redacted]	WPA2_1X	[redacted]	140	-72	40	2025.10.29 12:30:50
[redacted]	WPA2	[redacted]	149	-45	20	2025.10.29 12:32:12
[redacted]	WPA2_1X	[redacted]	161	-64	20	2025.10.29 12:33:55
[redacted]	Open	[redacted]	165	-57	20	2025.10.29 12:34:16

6.14 Obtaining troubleshooting information

Command for obtaining troubleshooting information

WEP-550K(root):/# **get-troubleshooting-file**

After the command is executed, an archive *troubleshooting.tar.gz* will be created, containing debug data and information about the device status.

The archive *troubleshooting.tar.gz* can be obtained from the device to a server via the TFTP protocol.

Command for obtaining troubleshooting information

WEP-550K(root):/# **tftp -pl troubleshooting.tar.gz <IP address of TFTP server>**

```
troubleshooting.tar. 100% |*******************************| 62755 0:00:00 ETA
```

The archive *troubleshooting.tar.gz* can be obtained from the device to a server/PC via the SCP protocol:

scp <user>@<IP address access point>:troubleshooting.tar.gz troubleshooting.tar.gz (example: scp admin@192.168.1.15:troubleshooting.tar.gz troubleshooting.tar.gz. This command is performed on the server/PC)

7 Auxiliary utilities

7.1 traceroute utility

This utility shows which nodes (routers) a packet passes through and how long packet processing takes at each node.

Traceroute command
WEP-550K(root):/# **traceroute <test host>**

7.2 tcpdump utility

The tcpdump utility allows capturing packets on the specified interface.

To get help on using the utility, enter the command:

```
WEP-550K(config):/# tcpdump --help
```

7.2.1 Capturing traffic from any active interface

For example, you can enable packet capturing on the Ethernet interface.

Command example
WEP-550K(root):/# **tcpdump -i eth0**

7.3 iperf utility

This utility is used to launch a traffic stream from one device to another. The sending side is called the client, the receiving side — server.

To get help on using the utility, enter the command:

```
WEP-550K(root):/# iperf --help
```

Example of launching a traffic stream from the access point to the server:

Configuring the server to receive traffic
root@server:/# **iperf -s**

Generating traffic from the AP client to the server
WEP-550K(root):/# **iperf -c X.X.X.X** (where X.X.X.X is the server IP address)

8 List of changes

Document version	Release date	Change description
Version 1.1	10.2026	Synchronization with firmware version 1.4.2 6.7 Configuring DHCP option 82 6.11 Configuring multiple controller addresses 6.12 Passive radio environment scanning manager configuration Changed: 5.6.2 "VAP" submenu 5.6.3 "MLO" submenu 6.3.7 Advanced VAP settings 6.4.4 Advanced MLO settings 6.13 Monitoring
Version 1.1	05.2026	Synchronization with software version 1.3.0 Added: 5.6.3 "MLO" submenu 5.9.7 "Troubleshooting" submenu 6.3.6 Configuring an additional RADIUS server on VAP 6.9 Configuring DAS server Changed: 5.5.3 "Radio 6 GHz" submenu 5.6 "VAP" menu 6.3.5 Configuring VAP with external Captive Portal 6.3.7 Advanced VAP settings 6.7.2 Device configuration management 6.7.5 Setting the date and time 6.8 Configuring Captive Portal parameters 6.10 Monitoring 6.11 Obtaining troubleshooting information
Version 1.0	03.2026	First publication
Software version 1.4.2		

TECHNICAL SUPPORT

For technical assistance in issues related to handling Eltex Ltd. equipment, please, address to Service Center of the company:

https://eltex-co.com/support/

You are welcome to visit Eltex official website to get the relevant technical documentation and software, to use our knowledge base or consult a Service Center Specialist.

http://www.eltex-co.com/

https://eltex-co.com/download/